

RINGER ADJUSTMENT

RINGER ADJUSTMENT
THE AMMATURE SHOULD BE SO ADJUSTED THAT THE CLAPPER BALL HAS A MOVEMENT OF ABOUT
THE AMMATURE SHOULD BE SO ADJUSTED THAT THE CLAPPER BALL
FROM THE CONTROL OF THE PROPERTIES AND THE POST SUPPORTS, WHEN THE CORRECT POSITION
19 OBTAINED, CLAMPT THE YORK EIRMYD SETTIMENT HENDED STANDING THE POST SUPPORTS, WHEN THE CORRECT POSITION
19 OBTAINED, CLAMPT THE YORK EIRMYD SETTIMENT HENDED THE LOST SUPPORTS, WHEN THE CORRECT POSITION
THE GONGS SHOULD BE SO SET THAT THE CLAPPER BALL STRIKES BUT DOES NOT REST AGAINST THEM WHEN
THROWN TO EITHER SIDE. TO CHANGE THE POSITION OF THE GONGS, FOR THE CLAMPING SCREWS "C"AND PUSH
THE GONGS, BY HAND, TOGETHER OR APART, AS DESIRED, UNTIL THE CORRECT POSITION IS, OBTAINED, AND
THEHREN DE CLAMPING SCREWS "C", TO ADJUST THE TEASHON OF THE BUSINGS STRING "S" TURN THE SCREWS "C".

RINGER CONNECTIONS

FOR BRIDGING SERVICE METALLIC LINE.

CONNECT THE REP WIFE "X" TO TERMINAL "C" AND THE GONNECT THE RED WIFE "X" TO TERMINAL "L".
BLACK WIRE "Z" TO TERMINAL "L".

CONNECT THE LINE WIRES FROM THE CENTRAL OFFICE TO TERMINALS"LI" AND "L2".

FOR 2-PARTY SELECTIVE AND 4-PARTY SEMI-SELECTIVE RINGING SERVICE.
ALWAYS CONNECT THE GROUND WIRE TO TERMINAL "GND".
CONNECT THE RED WIRE "X" TO TERMINAL "C"AND THE BLACK WIRE" Z" TO TERMINAL "GND" IN ALL SETS.

CONNECT THE TIP SIDE OF THE CENTRAL OFFICE LINE TO TERMINAL"LE"AND THE RING SIDE TO TERMINAL"LI". STATIONS ON TIP -

STATIONS ONRING -- CONNECT THE RING SIDE OF THE CENTRAL OFFICE LINE TO TERMINAL"LE THE TIP SIDE TO TERMINAL"LI".

