KEY SYSTEMS SERVICE MANUAL

VOLUME II

Bell System

TCI Library: www.telephonecollectors.info

Comments concerning content, usability, and adequacy of this manual will be welcomed. This sheet may be removed and mailed directly to the Bell System Practices Organization. This sheet is not to be used for ordering manuals. The following page will give you ordering information.

Mail To:

Bell System
Data Design Engineering Manager
2400 Reynolda Road
Winston-Salem, N. C. 27106

TCI Library: www.telephonecollectors.info

Orders for these manuals should be placed on:

Western Electric
Indiana Publications Center
P. O. Box 26205
Indianapolis, Indiana 46226

TCI Library: www.telephonecollectors.info

KEY SYSTEMS SERVICE MANUAL

VOL II

NOTICE
Not for use or disclosure outside the
Bell System except under written agreement

Printed in U.S.A.

TCI Library: www.telephonecollectors.info

INTRODUCTION

The Key Systems Service Manual consists of Volumes I, II, and III. Volume I contains three parts: Common Key System Information, General Apparatus, and Telephone Sets. Volume II contains information concerning 1A, 1A1, and 1A2 Key Telephone Systems. Volume III includes those BSPs unique to COM KEY* services. The sections are compiled in the manual numerically and not in the order they appear in the Table of Contents.

This manual supports plant craft personnel in their daily work operations. The sections contained in the manual provide information necessary for installing and maintaining key systems.

For information not included in this manual, refer to the standard BSP files.

*Trademark of AT&T Company

ISSUE 6, JULY 1980

TCI Library: www.telephonecollectors.info

TABLE OF CONTENTS
VOLUME I

	Section Number	Issue	Subject
COMMON INFORMATION			
	460-110-130	1	Marking Physical Location of Station Equipment and Cable
●	461-200-101	7	Connector Cables — Identification
	Add 461-200-102	1	
	461-200-102	6	Adapter for Use With Connector Cables
●	Add 461-604-100	1	
●	461-604-100	5	Connecting Blocks — 66-Type — Tools, Terminating, Adapters, and Maintenance
●	461-604-101	4	Connecting Blocks — 66-Type — Numbering and Wiring Plan
●	461-604-102	6	Connecting Blocks — 66A, B, C, and M1 Types — Identification
	461-604-103	3	Connecting Blocks — 66E3-25, 66E4-25, and 66E8-25 — Identification and Installation
●	461-604-105	2	Connecting Blocks — 66M3-50R and 66M4-50R — Identification, Installation, and Maintenance
●	461-608-100	3	Connecting Blocks and Wiring Blocks — 88-Type
	461-620-100	2	Matrix Block — 1A1 — Identification, Installation, Wiring, and Maintenance
●	Add 463-130-100	1	
	463-130-100	12	Backboards — Identification and Installation
●	463-140-100	9	Equipment Cabinets and Apparatus Mountings — Identification
●	463-210-100	5	Lamp Indicators — Identification and Installation
●	501-120-100	11	Buzzers and Bells — Identification, Installation, Maintenance, Limitations, and Connections
	501-150-102	5	Designation Strips and Cards
●	502-110-100	3	Key Telephone Sets — Standard Features and Options — Basic Wiring Requirements
●	Add 502-110-102	1	
	502-110-102	4	Nonkey Telephone Sets — Conversion for Use With 1A1 or 1A2 Key Telephone Systems
	502-500-120	4	Telephone Sets — 540, 560, 1560, and 2560 Series — Common Installation and Maintenance Information
	502-600-100	3	Telephone Sets — 630, 1630, and 2630 Series
●	512-210-101	4	Separately Mounted Keys — 6017-, 6026-, KS-21254-, and KS-21776-Types — Identification, Installation, and Connections
●	512-210-103	6	Separately Mounted Keys — 6040-, 6041-, 6050-, and 6051-Types — Identification, Installation, and Connections
●	512-220-100	7	549- and 551-Type Pushbutton Keys — Identification, Installation, Maintenance, and Connections
●	512-700-100	5	4A Speakerphone Components — Identification, Installation, Operation, and Maintenance
POWER			
	167-416-201	7	101G (J86731) Power Plants — Identification, Installation, and Connections
	167-440-201	6	Power Units — 19- and 20-Type — Identification, Installation, Connections, and Maintenance
	167-446-101	5	Power Units — 29- and 30-Type — Identification, Installation, and Connections
	167-447-101	1	Power Units — 34B1 and 34C1 — Identification, Installation, and Connections
●	167-449-101	2	Power Unit — 47C — Identification, Installation, and Connections
TELEPHONE SETS			
SERVICE			
●	502-501-100	1	554BMS and 2554BMS Telephone Sets — Identification, Installation, and Maintenance
	502-541-406	2	564HD
●	502-541-407	5	564HK, 564HL, 564HLM, and 564HLMS
	502-541-410	2	565HD
●	502-541-414	6	565GK, 565GKM, and 565GKMS
●	502-541-415	8	565HK, 565HKM, and 565HKMS
●	502-541-416	8	565LK, 565LKM, and 565LKMS
●	502-543-403	6	2565GK and 2565GKM
●	502-543-405	8	2565HK, 2565HKM, and 2565HKMS
●	502-543-406	8	2565LK, 2565LKM, and 2565LKMS
	502-580-405	4	500L/M and 500MM
●	502-582-400	5	2500M and 2500MM
	502-610-406	2	630A, B, C, D and 631A, B, C, D
●	502-610-407	8	630DA, 630DAM, 630DAMS1, 631DA, 631DAM, and 631DAMS1

TCI Library: www.telephonecollectors.info

	Section Number	Issue	Subject
●	Add 502-610-409	1	
	502-610-409	2	634A, B, C, D and 635A, C, D
	502-610-410	2	636A, B, C and 637A, B, C, D
	502-610-417	5	634DA, 634DAM, 635DA, and 635DAM
●	502-610-418	6	636CA, 636CAM, 636CAMS, 637DA, 637DAM, and 637DAMS
	502-612-400	3	2630D and 2631D
●	502-612-401	6	2630DA, 2630DAM, 2631DA, and 2631DAM
	502-612-403	2	2634D and 2635D
	502-612-404	1	2636- and 2637-Type
	502-612-409	5	2634DA, 2634DAM, 2635DA, and 2635DAM
	502-612-410	5	2636CA, 2636CAM, 2637DA, and 2637DAM
●	503-601-101	8	851- and 2851-Type
●	503-603-101	4	2872A1M or 2872A2M — (TOUCH-A-MATIC Automatic Dialer)
●	503-603-102	2	872A1M (TOUCH-A-MATIC Set)
●	503-701-101	9	830- and 2830-Type
●	503-702-101	9	831- and 2831-Type

VOLUME II

KEY TELEPHONE SYSTEMS — 1A, 1A1, AND 1A2

COMMON INFORMATION

	518-010-101	2	Centralized Key Telephone Installations
	518-010-105	2	Key Telephone System — Grounding and Special Protection Requirements
	518-010-106	3	Power Unit Selection — Key Telephone Systems and Key Service Units
	518-010-107	1	Key Telephone Systems — Reserve Power — 47C Power Unit
●	518-010-108	4	Common Audible Signaling — Key Telephone Systems
●	518-010-109	2	Voice Station Signaling on Manual Intercoms — Identification, Installation, and Maintenance
	518-010-110	1	2A1 Matrix Block — Identification, Installation, Connection, and Maintenance
●	Add 518-010-111	1	
	518-010-111	2	Message Waiting Consoles Used With 1A, 1A1, or 1A2 Key Telephone Systems
●	518-010-115	2	Hands-Free Answering on Intercom — 1A1, 1A2, 6A, and 6B Key Telephone Systems
●	518-010-116	1	Paging Adapter Circuit — 278A Adapter
●	876-300-100	8	Electrical Protection — Stations and Customer Premises Equipment

SERVICE — 1A KTS

	518-112-420	1	50-Type Packaged Units
	518-112-421	2	Tie Line and Control Services
	518-112-422	1	Intercom Services

REFERENCE — 1A1 KTS

●	518-114-105	2	Identification and Arrangements
●	518-114-108	2	Installation and Maintenance
●	518-114-110	4	Key Telephone Units
	Add 518-114-115	1	
	518-114-115	1	Packaged Key Telephone Units
	518-114-116	2	TOUCH-TONE Adapters

SERVICE — 1A1 KTS

	518-114-425	3	Key Telephone Units
	518-114-430	1	200F, G, and K Packaged Key Telephone Units
	Add 518-114-431	1	
	518-114-431	3	200H Packaged Units
	518-114-432	1	Key Service Units

REFERENCE — 1A2 KTS

●	518-215-100	7	Identification and Arrangements

SERVICE — 1A2 KTS

●	518-215-400	7	Key Telephone Units — Line Services
●	Add 518-215-401	1	
	518-215-401	3	Key Telephone Units — Auxiliary Line Services
●	518-215-402	4	Key Telephone Units — Intercom Services
	518-215-403	2	Key Telephone Units — Control Services
●	Add 518-215-404	1	
	518-215-404	1	Key Service Units — 501- and 502-Type
●	Add 518-215-405	1	
●	518-215-405	7	Key Service Units — 513-, 514-, and 515-Type

TCI Library: www.telephonecollectors.info

	Section Number	Issue	Subject
●	Add 518-215-407	2	
	518-215-407	1	Key Service Units — 550- and 551-Type
●	Add 518-215-410	1	
●	518-215-410	8	Panels — 583- and 584-Type
●	518-215-417	7	Panels — 597- and 598-Type
	518-215-418	2	Panels — 601-, 602- and 603-Type
●	518-215-419	5	Modular Panels — 620A (MDI), 641A, and 642A
●	Add 518-215-420	1	
●	518-215-420	6	Apparatus Mountings — 69B, D, and G
●	Add 518-215-421	2	
●	518-215-421	2	Modular Panel — 626A
●	518-215-422	3	Apparatus Mounting — 110A
●	518-215-424	1	630 Key Service Panel and 113A1 Connecting Unit — Identification, Installation, and Connections
●	518-411-100	2	6B Key Telephone System — DIALOG Intercom System
	518-300-413	4	259-Type Key Telephone Unit — Identification
	518-300-417	1	272A Key Telephone Unit — Identification

COMMON KTUs

	518-310-401	2	227A (MDI) and 227B Key Telephone Units — Audible and Visual Signaling — Identification and Connections
	518-310-405	5	Station Line Concentrators — 235- and 236-Type Key Telephone Units — Identification and Connections
	518-310-407	8	Key Telephone Unit — 237-Type — Identification, Operation, and Connections

VOLUME III

COM KEY® TELEPHONE SETS

●	503-603-120	3	575AM and 2575AM
●	503-701-110	4	832- and 2832-Type
●	503-702-110	4	833- and 2833-Type

COM KEY SYSTEMS

●	Add 518-450-100	1	
●	518-450-100	4	7A Communication System — (COM KEY 718)
●	Add 518-450-102	2	
	518-450-102	3	14A Communication System — (COM KEY 1434)
	518-450-105	2	4A Communication System — (COM KEY 416)
●	518-450-106	3	4A Communication System — (COM KEY 416) Using 981/2981- and 983/2983-Type
●	Add 518-450-110	1	
●	518-450-110	2	21A Communication System — (COM KEY 2152) — Descriptive and Ordering Information

● Indicates sections that have been addended, reissued, or added since last issue of manual.

TCI Library: www.telephonecollectors.info