FIG. 1
RELAY SET

FIG. 2
LINE LAMP AND JACK ON MANUAL BOARD

FIG. 3
DIRECT EXTENSION NIGHT SERVICE JACK ON MANUAL BOARD

FIG. 4
VISUAL ENGAGED LAMP

NOTES:

1. FUSE 1·5A PER CIRCUIT (FIG. 1), 1·5A PER POSITION (FIG. 4).
2. U POINTS 9-11, 17-19 & 59-61 MAKE CONTACT WHEN THE RELAY SET IS REMOVED.
3. RELAY DR IS DIFFERENTIALLY CONNECTED.
4. MODIFY LINE CCT. AT MAIN EXCHANGE (SEE INSTALLING SPECIFICATION).
5. Ø FOR WIRING SEE GBW 14380 OR EQUIV.
6. WHEN ASSOCIATED WITH NIGHT SERVICE ACCESS CCT. CUT STRAPS SHOWN —•—•— & —x—x— AND ADD CONNECTIONS SHOWN —o—o—.
7. WHEN DIRECT EXTENSION NIGHT SERVICE IS SPECIFIED FIT N.S. JACK (FIG. 3) ON MANUAL BOARD, CUT STRAP SHOWN —•—•—•— OMIT CONNECTIONS SHOWN —I—I—I— AND ADD CONNECTIONS SHOWN — — — — — —.
8. ALL WIRING TO BE 0·5mm EXCEPT WHERE OTHERWISE SHOWN.
9. WHERE THE ULTIMATE NUMBER OF EXCHANGE LINES IS 15 OR LESS, THEY WILL NORMALLY BE CABLED DIRECTLY TO THE SELECTOR MULTIPLE, OTHERWISE VIA A T.D.F. OR GRADING SHELF.
10. WHEN VISUAL ENGAGED SIGNAL IS REQUIRED ADD LAMPS ON MANUAL BOARD (FIG. 4) AND ADD CONNECTION SHOWN —11—11—.
11. STRAP U POINTS 73-75 WHEN IMMEDIATE BUSY FACILITY IS REQUIRED ON INCOMING CALLS FROM RING RETURN EARTH MAIN EXCHANGE, STRAP U-POINTS 71-73 FOR RING RETURN BATTERY MAIN EXCHANGES.
12. IN ORDER TO BUSY THE CIRCUIT MOVE THE TEST LINKS FROM TJ13-14 AND TJ11-12 TO TJ7-8 AND TJ9-10 RESPECTIVELY.

BATT. V. 0·7mm FUSE — 1B2 — R1b (FIG. 2) — U12

ETH. R. 0·7mm ETH BAR — 1A2 — U11-U61

ETH. R. U11-T1E-T110-SR21-DR21-DRb-DR3-CA1-CC23-AC2-ACe-ER1-ER7-H28-OH21-YA-Y21-MH2-CRa-CR2-CR8-CB3-CB8-LS4-ST21-ST5-BB22-B25-B1-B3-R11a-R3a-R2a-TU8-TJ10.

BATT. V. U12-SRe-DRe-CAe-CCb-CCe-ERe-He-OHe-RHe-CRe-CBe-STe-BBe-Be-A7-R4b-R7b-R13b-R9b-R10b.

SUPERSEDES GBW 15220 MOD A

PREPARED FROM GBW 16990 ISS. 1 OF 19·4·72 (99993)

AMENDMENT PARTICULARS

EXCHANGE LINE CIRCUIT 50/1200 LINE P.A.B.X. MAGNETO MAIN EXCHANGE

ISSUE | DATE | APPD | REF:- | SIZE: A1 | 30V | W

NZPO | DRAWN M.S. | CHECKED | WIRING | CIRCUIT A.J. | GBW 16990 MOD A

0 5 Centimetres 10 15 20 25 30 35