

IMPORTANT

INSTRUCTIONS FOR CONVERTING STANDARD TELEPHONE TO TWO-STEP HOOK SWITCH TYPE TELEPHONE

1. Change Blue Lead of Hook Switch From 4 to 9
 2. Change Green Lead of Handset from 6 to 4
 3. Change Yellow Lead of Handset from 10 to 6
- IF DIAL IS USED, CHANGE AS FOLLOWS:
1. Change Red Lead From 5 to 11

TO CONVERT No. 1242 & No. 1243 TELEPHONES FOR USE WITH STROMBERG-CARLSON No. 1180 MAGNETO DESK SET BOX, CHANGE AS FOLLOWS:

1. Remove Strap B
2. Remove Strap Connecting 11 to 12
3. Remove Strap 9 to 10
4. Remove Strap G to L-2
5. Reverse L-2 and G
6. Remove Both Ringer Leads
7. Move Red of Hook Switch From 8 to 10
8. Move Red of Handset From 8 to 1
9. Add Strap from G to 4
10. Connect Line Cord to Corresponding Colored Terminals in Desk Set Box

CONVERSION PROCEDURE FOR USE WITH No. 4H & No. 5H W. E. CO'S. DIALS

1. Remove Strap 5 to 6
2. Move Green of Receiver From 6 to 5
3. Connect W on Dial to 5
4. Connect BB on Dial to 6
5. Connect R on Dial to 7
6. Connect BK on Dial to 3
7. Connect Y on Dial to 1