



NOTES:

- 1- WHEN NO DIAL IS USED, PLACE BOTH YEL. & BL DIAL LEADS UNDER SCREW IN DIAL HOLE COVER & TAPE WH & RED DIAL LEADS SEPARATELY TO INSULATE FROM CIRCUIT
- 2- "X" CONTACTS TO BREAK FIRST AND MAKE LAST.
- 3- (A) CONNECT LINE WIRES TO TERMINALS 1 & 2 (L1 & L2).
- (B) WHEN RINGER BOX IS USED AND IS EQUIPPED WITH A CAP, CONNECT LEADS FROM RINGER BOX TO TERMS 1 & 2 (L1 & L2).
- (C) WHEN RINGER BOX IS USED AND IS NOT EQUIPPED WITH A CAP, CONNECT LINE

- LEADS FROM RING BOX TO TERMS 1 & 2 (L1 & L2), AND CONNECT THIRD LEAD FROM TERM "R" OF RING BOX TO TERM 3.
- 4- (A) FOR SATT DIALING, CONNECT LINE WIRES TO TERMS 1 & 2 (L1 & L2) AND GROUND LEAD TO UN-NUMBERED TERM (G).
 - (B) USE RING BOX EQUIPPED WITH CAP & CONNECT LEADS PER NOTE 4(A).
 - (C) SPOTTER SPRINGS TO OPERATE WHEN PULSING SPRINGS ARE CLOSED.
 - 5- LEADS ON 100 & 62 OHM RESISTORS ARE PART OF RESISTORS.

H-54423, ISSUE 5

Wiring Diagram, Type 83 Telephone.