





Wiring Diagram of No. 1155 Type Wall Telephone


WIRING DIAGRAMS

FOR No. 1182 TELEPHONE, MANUAL
TYPE, BOOSTER CIRCUIT




NOTE: FOR SIDE TONE REDUCTION REVERSE RED AND YELLOW CONDUCTORS ON CONNECTING RACK

No. 1182-A TELEPHONE, MANUAL,
ANTI-SIDE-TONE CIRCUIT



NOTE: WHEN 1182-A TEL. IS USED WITH 1156 BELL BOX
CONNECT RED OF LINE CORD TO L-2 AND YEL-
LOW OF LINE CORD TO 2-R.


WIRING DIAGRAM FOR THE 1201-CA TELEPHONE




Wiring Diagram of No. 1211-A Telephone

STROMBERG CARLSON TEL. MFG. CO.
WIRING DIAGRAM NO.1211-A TELEPHONE


PLUG ON END
OF DIAL
CORD




PLUG ON END
OF DIAL
CORD



MANUAL
PLUG END
OF CORD






REMOVE TERM.
BLOCK WHEN
DIAL IS USED










NOTE: TO CHANGE FROM BRIDGED TO DIVIDED
CIRCUIT RINGING REMOVE ORANGE WIRE
FROM 'L-2' AND PLACE ON 'GRD.' AS SHOWN
BELOW FOR TIP OR RING STATION.

BRIDGED CIRCUIT
RINGING

DIVIDED CIRCUIT RINGING
TIP STATION RING STATION








NOTE—TO CHANGE FROM BRIDGED TO DIVIDED CIRCUIT RINGING, REMOVE ORANGE WIRE FROM TERM. "F" AND PLACE ON TERM. "H" AS SHOWN ABOVE FOR TIP AND #1-TERM. IND. COIL

TO CONVERT FROM MANUAL TYPE TO DIAL TYPE TELEPHONE REMOVE TERMINAL BLOCK AND REWIRE LEADS TO DIAL AS SHOWN.

HOOK SWITCH

WHITE
BROWN
X TO MAKE BEFORE Y



IN BRIDGED RINGING, WHERE IT IS NECESSARY TO PREVENT TAPPING OF GONGS ON #121A RINGERS WHILE DIALING, POSITIVE BATTERY SHOULD BE CONNECTED TO L-1 AND BIAS SPRING TENSION THEN ADJUSTED AS REQUIRED.

"NOTE"

① THIS WIRING DIAGRAM IS FOR THE #1222 TELEPHONE. IN THE #1223 TELEPHONE THE WIRING INDICATED BY DASH LINE IS MODIFIED AS SHOWN BELOW PER FIG. A, B, C, D, E, F, G, OR H, ACCORDING TO THE CIRCUIT REQUIRED.

② WHEN #615 RINGER IS USED, MOVE ORANGE OR RED WIRE FROM TERMINAL G TO TERMINAL K.

③ WHEN USING THE W.E.#333A TUBE IN SUPERIMPOSED RINGING, THE EXTREME LOW & HIGH SETTINGS OF BIAS SPRING TENSION AT WHICH THE RINGER WILL ALWAYS START SHOULD BE DETERMINED BY TEST & THE FINAL SETTING SHOULD BE MIDWAY BETWEEN THESE TWO EXTREMES.

METHOD OF CONNECTING #1223 TELEPHONE FOR DIVIDED CIRCUIT RINGING





METHOD OF CONNECTING #1223 TELEPHONE EQUIPPED WITH VINCENT RARE GAS RELAY FOR DIVIDED CIRCUIT RINGING

RING STATION

TIP STATION

RING STATION

TIP STATION







METHOD OF CONNECTING No. 1223 TELEPHONE EQUIPPED WITH WESTERN ELECTRIC CO.'S #333-A VACUUM TUBE FOR PULSATING OR SUPERIMPOSED RINGING (SEE NOTE 3)


+ ON TIP STATION

+ ON RING STATION


- ON TIP STATION


- ON RING STATION






Line Drawing showing a No. 1224-A Telephone connected to a Typical Desk Set Box (No. 1156-ADB)







Wiring Diagram of No. 1217-A and No. 1218-A Chime Signal Boxes




Wiring Diagram of No. 1220-A Chime Signal Box




Wiring Diagram of No. W-1218-A Chime Signal Box



Wiring Diagram of No. 1226 Desk Set Box




Wiring Diagram of No. W-1226 Desk Set Box



No. 896 Wood Wall Telephone


Wiring Diagram

MAGNETO WALL PHONE (HANDSET TYPE)




Wiring Diagram


D-2843 and D-2844 Wood Handset Telephones



**Wiring Diagram of
No. 15 Handset**




**Wiring Diagram of
No. 16 Handset**



- | Code No. | Description |
|-------------|---|
| 19-C | Used with Central Energy Systems as a test set or as an extension Telephone. Equipped with a 2 conductor Duratex Cord, MC-2C 6'0" |
| 19-D | Used for testing and service observation in machine ringing systems. Equipped with a condenser and 2 conductor Duratex Cord, MC-2C 6'0" |
| 19-L | Used on No. 843 Test Set portable field telephone. Equipped with 3 conductor Duratex Cord, MC-3B 6'0" |

WIRING DIAGRAM
HANDSET # 20



WIRING DIAGRAM HANDSET #21

