
BELL SYSTEM PRACTICES Station Operations Manual Coin Stations

COIN COLLECTORS — POSTPAY — 150K, L; 162A, B, C, D MANUAL — COMMON BATTERY — CONNECTIONS



SEE NOTES ON FACING PAGE

Fig. 1 — Circuit Diagram Used with 634A, BA, and BC; 684A, BA, and BC Induction Coil Subscriber Sets.

Note 1: In some upper housings, terminals may be designated W, BB, YY, Y, BK-YY, respectively. Terminal 5 is not always furnished.

* Leads enclosed in tape are to be used only when coin collector is connected for prepayment service.