



	CONTENTS	PAGE
1.	GENERAL . . . . .	1
15.1	SD-95690-01 . . . . .	2

**1. GENERAL**

**1.01** This section provides an index and information access system to locate the standard tests applicable to equipment listed in the preceding table of contents. Test classification and frequency of periodic routine are also provided.

**1.02** This Equipment Test List (ETL) is reissued to incorporate changes which are indicated by an arrow to the left of each line which has been changed.

**1.03** Comments on this section should be made by following the instructions in Bell System Practices (BSP), Section 000-010-015.

**1.04** Routine test information is arranged in the following order from left to right: Section number, issue/addendum, test letter or paragraph number, test title, test class, frequency, and the last space is for a locally assigned job number.

**1.05** Section 010-300-011 provides Equipment Test List instructions.

**NOTICE**

Not for use or disclosure outside the  
Bell System except under written agreement

◆15.0 EMER LINE CKT

◆ 15.1 EMER LINE CKT; SD-95690-01

◆ TROUBLE TESTS

◆	201-650-501 (1/0)	A	OPERATION OF TEST & ALARM CKT	TT	-----
◆		B	FUSE ALARM FEATURES	TT	-----
◆		C	OPERATION OF EXTENSION ALM CKT	TT	-----
◆		D	TEST OF DRY BATTERIES	TT	-----
◆		E	STANDBY TRANSFER FEATURE	TT	-----