

E.W. GRUSSING - OAK PARK

TRAINING TEXT  
OPERATIONAL SKETCH  
&  
SEQUENCE CHART  
755-A  
DIAL P.B.X.



JUNE 1956

P.T.S. 508.3

**Developed by**  
**The Plant Training Schools**

**For Training Purposes Only**

## PREFACE

This outline has been prepared as a guide for the instructor to enable him to make full use of the apparatus and materials provided for use in this class. The teaching sequence as outlined is largely the result of experience and should be closely followed in order to obtain uniform results.

Reference to Bell System Practices are to latest issues at the time this outline is published. It will be necessary for the instructor, therefore, to check subsequent issues of practices, making corrections as necessary in this outline. When such corrections are necessary, they should be made in all existing copies of the outline.

If after considerable experience in teaching the class from this outline the instructor feels that changes should be made or if he wishes to introduce new ideas and materials, such changes should be discussed with Plant School Supervision. Should the discussion result in a decision to make such changes, appropriate steps will be taken to have this outline republished.

INDEX

<u>Subject</u>	<u>Page</u>
Introduction - - - - -	1
Outward Call to Central Office - - - - -	2
Look-Out Service - - - - -	4
Restricted Service - - - - -	4
Incoming Central Office Call - - - - -	5
Answering Trunk Call - - - - -	6
Holding Trunk Call - - - - -	6
Reseizure of Trunk - - - - -	6
Incoming Trunk Call Abandoned - - - - -	7
Abandoned Trunk Call - - - - -	7
Station to Station Call - - - - -	10
First Digit - - - - -	12
Second Digit - - - - -	13
Called Line Idle - - - - -	16
Timing Circuit Automatic Ring - - - - -	17
Key Station Answers - - - - -	20
Called Station Busy - - - - -	20

LEGEND



RELAY WINDING



CIRCUIT THROUGH NORMAL RELAY, CONTACTS 1 TO 2      TOP



CIRCUIT THROUGH OPERATED RELAY, CONTACTS 1 TO 2 BOTTOM


The 755-A P.B.X. is a small dial telephone system employing crossbar switches and U and Y type relays. It provides dial intercommunicating service and outside trunk service without an attendant. It is designed to serve small business houses and large residences, and replaces the 750-A P.B.X. The capacity of the 755-A P.B.X. is 20 station lines, 4 trunks, and 3 intercommunicating links.


The principal features of the equipment are summarized as follows:

- (a) Dial intercommunicating service.
- (b) A crossbar switch is used as a switching device, which eliminates all moving parts.
- (c) All incoming central office calls can be answered and transferred at any key station.
- (d) Key stations may or may not, as desired, be arranged for outgoing central office calls.
- (e) Provision of a combined dial hand telephone set with the necessary key buttons mounted in the base for establishing local and trunk service.
- (f) A control key arrangement is available for use at key stations to provide means for connecting keyless type stations to central office trunks without limiting the use of the key station.
- (g) One or more key stations may be connected as extensions of a main key station.
- (h) Arrangements are provided to permit line hunting on certain lines when required.
- (i) Local conference connections may be established by dialing.
- (j) Trunk lamps may be provided at the stations and are arranged to flash to indicate unanswered calls and to light steadily when their associated trunks are busy.
- (k) Lamp signals similar to those used for trunks may be provided for local lines.
- (l) Tie trunk service to other P.B.X.'s.
- (m) One station may pick up calls directed to another station by means of a special key.
- (n) Outgoing service on wiring plan trunks.
- (o) Trunk service to a disassociated telephone.



The following circuit code covers the main functions of the 755-A P.B.X. and does not take into consideration all the special features which may be used. Information on any item which is not covered in this book should be obtained from S.D. and C.D. sheets.

**TRUNK CALL TO CENTRAL OFFICE**







LOCK OUT STATION CLOSES ON BUSY TRUNK



RESTRICTED STATION ATTEMPTS C.O. CALL




## **INCOMING TRUNK CALL**




A-B-D CYCLE PROVIDES FLASHING LAMP


Answer Incoming Call



Trunk Call Held




Held Call Answered



INCOMING TRK. CALL ABANDONED

C.O.RINGING  
STOPPED




R1 RELAY REMAINS LOCKED TO GROUND AT THE Z3 RELAY

THE A,B,D, RELAY ACTION WILL CONTINUE UNTIL THE R1  
RELAY RELEASE - TRUNK LAMP CONTINUES TO FLASH


THE B RELAY CONTROLS THE OPERATION OF TIMING CIRCUIT

ABANDONED TRUNK CALL


C.O. Q.E.H.




SHUNT Z




W, Z, W1, Z1, SAME AS SHOWN ON LOCAL CALL EXCEPT THAT GROUND IS NOW SUPPLIED FROM R1 IN TRK, INSTEAD OF SP IN LINK




STEP #1




SHUNT Z2




STEP #2




STEP #3





STEP #4




(SHUNT REMOVED)


STEP #5



STEP #6




STEP #7




(BY SHUNT) HOLDS Z2


(BY SHUNT) HOLDS Z3

THE RELEASE OF THE RI (TRK) REMOVES GROUND  
FROM THE ST AND RI LEADS ALLOWING THE ENTIRE TIMING  
CIRCUIT TO RESTORE TO NORMAL AND EXTINGUISHES THE  
TRK LAMP






= LOCAL DIAL TONE




STATION DIALS TENS DIGIT (#3)


1st Pulse




2nd Pulse



### 3rd PULSE




### Removes P2 Shunt




C Relay, Slow release, remains operated during Pulses Holding Sw.


DIALING UNITS (#7)




### 2nd Pulse




### 3rd Pulse




### 4th Pulse




### 5th Pulse





### 6th Pulse




### 7th Pulse









**TIMING CIRCUIT  
AUTOMATIC RINGING**






### STEP #1





### STEP #2




Release Gen.  
connect trip Batt. & Grd.  
Release Audible Ring.

### STEP #3



STEP #4



STEP #5




Same as Step #1  
Lock W - Shunt Z

STEP #6




Same as Step #2


STEP #7



By Shunt (See Step #3)



STEP #8




Connects Gen. & Audible Ring  
Releases Trip Batt. & Grd.


The above circuit provides one cycle of Generator and three cycles of silent period.

Each cycle approximately one second duration.

CALLED STA. 37 ANSWERS



P.B.X. SYSTEMS  
DIAGRAM OF CONNECTIONS TO CROSSBAR SWITCHES IN 755A P.B.X.



MEMORANDUMILLUMINATED KEY BUTTON TELEPHONE SETS  
FOR USE WITH 755-A P.B.X. SWITCHBOARDS

Illuminated key button telephone sets have recently been introduced as standard alternate equipment for stations connected to 755-A P.B.X. switchboards. The sets are equipped with #51-A lamps for visual signals on trunk calls and local calls. Power to operate the lamps, which are rated at 10 volts, is supplied from the local battery (18-25 volts) or centralized battery through a resistance element wired in the lamp circuit to provide the specified voltage.

Illuminated key sets impose a heavier drain on the local batteries than lamp indicators due to the additional appearances of trunk lamps. It would be necessary in most cases, dependent on traffic and number of key sets, to replace or supplement the local batteries with a higher capacity power plant and provide additional charging facilities. Inasmuch as there is no suitable power plant available, an economical and satisfactory method of supplying power to operate the system can be effected by using local 110 volt, 50-60 cycle power with a 393-A transformer to furnish 10 volts for the lamps in the key sets, and continue using the local battery for all other features of the P.B.X.

The following paragraphs give wiring changes and associated information pertaining to modification of the 755-A P.B.X. trunk circuit to operate the trunk lamp from 50-60 cycle power. Modification of the line circuit is also included for cases where a visual signal is to be provided for local calls. These changes of wiring will be in effect until the standard drawings which are in the process of development are available. The "SD" and "T" drawings involved are to be marked to show the necessary changes and left at the P.B.X. for maintenance forces.

Connecting Block Wiring

The pairs indicated below are to be strapped common for required number of stations at the cross-connecting terminal per B.S.P. B556.015, Table I, and a #20AM lead run to Terminal Strip "A" as follows:

Pairs 152-161, inclusive, to misc. term. #1
" 162-171, " " " "#2
" 172-181, " " " "#3
" 182-191, " " " "#4
" 192-201, each pair strapped individually when required for station line lamps and a lead run to misc. term. #17, 23, 35, 41 or 47, 29.

Wiring Changes

## 1. 755-A Trunk Circuit - T-66503-11

- (a) Remove (Battery) red lead from 2B of the (B) relay and 3B of the (H2) relay. (See note 1)
- (b) Remove the "LB" lead from 1B of the (T) relay. (See note 1)

- (c) Strap 2B of the (B) relay, 3B of the (H2) relay, and the "LB" lead together and extend the lead to the "A" terminal of the 393-A transformer. Tape splice of "LB" lead.
2. Station Line Lamp Circuit - T-66506-11
- If station line lamp is required, a flashing call lamp can be provided, using A.C. power, but a steady busy lamp will not be available due to circuit conditions.
  - Remove and tape battery lead from 2B of the (B) relay.  
(See note 2)
  - Remove fuse (C) at fuse panel (Signal).
  - Run a lead from 2B of the (B) relay to "A" terminal of the 393-A transformer.

Note 1 - Corresponding terminals per SD-66503-11 are 8B of the (B) relay, 6B of the (H2) relay, and 3B of the (T) relay.

Note 2 - Corresponding terminal per SD-66506-11 is 8B of the (B) relay.

#### 393A Transformer

- Wire 393-A transformer per SD-69091-0120, Fig. 31, and install per B.S.P. C53.511.
  - 36 Lamps may be connected to one transformer.
  - Use one transformer for each trunk when the 755-A P.B.X. is fully equipped with 20 stations.
  - One transformer may be used for more than one trunk in so far as the capacity of the transformer is not exceeded.
  - All lamps for an individual trunk are to be connected to the same transformer.
- 325 LAMPS RT2 TRANSFORMER*

**C - 755A**

**COURSE 451**


**PLANT TRAINING COURSE**

**STUDENT MATERIAL FOR 755A P.B.X.**

**OPERATIONAL SKETCHES AND SEQUENCE CHARTS**


**Michigan Bell Telephone Co.  
General Plant Personnel  
March, 1959**


- 101 755A PBX EQUIPMENT  
102 BLOCK SCHEMATIC, STATION 25 CALLING STATION 32  
103 CROSSBAR SWITCH - VERTICAL UNIT  
104 PICTURES 100 AND 200 POINT CROSSBAR SWITCHES  
105 CROSSBAR SWITCH SELECTING MECHANISM  
106 CARD OPERATED MECHANISM  
107 FIG. A GENERAL VIEW-NOMENCLATURE  
108 PARTIAL PERSPECTIVE VIEW 20 VERTICAL UNIT SWITCH  
109 FIG. B METHOD OF COUNTING CONTACTS  
110 149C TERMINAL STRIPS A AND B  
111 LIST OF RELAYS AND LOCATIONS ON OS DRAWINGS  
112 SEQUENCE CHART NO. 1 LOCAL CALL TO STATION 32  
113 SEQUENCE CHART NO. 1 CONTINUED  
114 SEQUENCE CHART NO. 1 CONTINUED AND NO. 2 TRUNK CALL  
115 OS-1 OPERATION OF LINE L-RELAY  
116 OS-2 SELECT LINK  
117 OS-3 CLOSING CROSSPOINT AT ORIGINATING END OF LINK  
118 OS-4 PULSE COUNTING  
119 OS-5 REGISTER TENS DIGIT DIALED  
120 OS-6 REGISTERING UNITS DIGIT  
121 OS-7 TESTING LINE FOR BUSY AND LINE HUNTING 26 & 36  
122 OS-8 RECEIVING BUSY SIGNAL  
123 OS-9 OPERATION OF SELECT MAGNET CALLED END OF LINK  
124 OS-10 RINGING CALLED STATION  
125 OS-11 INDICATION OF IDLE LINKS  
126 OS-12 SLEEVE & HOLDING PATHS, TRUNK CLASS FOR STATION  
127 OS-13 TIP AND RING ON TRUNK CALL  
128 OS-14 FLASHING TRUNK LAMP ON INCOMING CALL



755A PBX  
EQUIPMENT

755A PBX  
451-101






CROSSBAR SWITCH - VERTICAL UNIT

BELL TELEPHONE LABORATORIES, INC.

CROSSBAR SWITCHES

451-104

20-VERTICAL UNIT 200-POINT CROSSBAR SWITCH



10-VERTICAL UNIT 100-POINT CROSSBAR SWITCH






FIG. 2  
CROSSBAR SWITCH  
SELECTING MECHANISM


HOLD MAGNET OPERATED; SELECT MAGNET NORMAL  
(LOWER CROSS POINT OF A PAIR OPERATED)




# MECHANISM


## CARD OPERATED







PARTIAL PERSPECTIVE VIEW OF 20-VERTICAL UNIT CROSSBAR SWITCH (200 POINT)



451-110  
755A PBX

149C TERM. STRIP B


+ STA + LINES + MISC + + + + +


SD-66504-01


RELAY	LINE, LINE SWITCH AND CALL ALLOTTER	OS
B	BREAK SEL. MAG. OPERATING GROUND	9
CO-	CUT-OFF LINE GROUND AND OPERATE LINE HOLD MAG.	2, 7, 12
E	END OF CHAIN CIRCUIT	2, 9
E1	END AUXILIARY NO. 1	2, 9
E2	END AUXILIARY NO. 2	2, 9
HOLD MAG.	LINE HOLD MAGNET	3
L-	LINE RELAY 20 to 29 AND 30 TO 39	1, 4, 8, 13
LI-	LINE AUXILIARY NO. 1	2
LL	LINE LAMP	-
LK	LINK 1, 2 or 3	9
M	TIMING FOR EMERGENCY OPERATION OF SEL. MAG.	3, 9
MS	START THE OPERATION OF SEL. MAG.	3, 9
N	TIMING FOR EMERGENCY OPERATION OF SEL. MAG.	3, 9
S	START CLOSING CROSSPOINT	3
S1	START CLOSING CROSSPOINT AUX. NO. 1	3
SEL MAG.	SELECT MAGNET	3, 9
SW	SWITCH TIP AND RING FROM OTHER STATION	-
TK	TAKE-UP OTHER STATION	-
	SD-66611-01	
	LINK AND LINK ALLOTTER	
1-7	UNITS DIGIT DIALED 1 OR 7	6, 7
2-8	UNITS DIGIT DIALED 2 OR 8	6
3-9	UNITS DIGIT DIALED 3 OR 9	6
4-0	UNITS DIGIT DIALED 4 OR 0	6
5-6	UNITS DIGIT DIALED 5	6
6	UNITS DIGIT DIALED 6 OR MORE	6
A	SUPERVISORY RELAY CALLING STATION	4, 8
B	BUSY LINK	4
BY	BUSY CALLED STATION	7
C	COMPLETION OF DIALING A DIGIT (SLOW RELEASE)	4
C1	C RELAY AUXILIARY NO. 1	5
CH-	CHANNEL OR LINK NO. L, 2, OR 3	11
DC	DIALING COMPLETED	5
E	SUPERVISORY RELAY CALLED END	8, 10
IS	HOLD SLEEVE	12
P1	PULSE COUNTING RELAY NO. 1	4
P2	PULSE COUNTING RELAY NO. 2	4
P3	PULSE COUNTING RELAY NO. 3	4
R	RING THE CALLED STATION	10
SP	SPLIT THE TALKING PATH FOR RINGING	10
ST	START THE LINK	2
SW	SWITCH PULSING FROM TENS TO UNITS	5
T2	TENS TWO	5
T3	TENS THREE	5
TL	TIE LINE	-

SD-66503-01


RELAY	TRUNK	OS
B	BUSY TRUNK	12
H	HOLD TRUNK	12
H1	HOLD TRUNK AUX. NO. 1	13
H2	HOLD TRUNK AUX. NO. 2	13
L	LINE RELAY FOR PERMANENTLY CONNECTED STATION	--
R	RING-UP RELAY	13
R1	RING-UP AUXILIARY NO. 1	14
T	TRUNK SELECT MAGNET RELAY	12
	SD-66506-01	
	TONE, RINGING, ALARM AND COMMON TIMING	
A	FIRST RELAY OPERATED	10, 14
B	SECOND RELAY OPERATED	8, 14
BY	BUSY TONE FOR LINES	2
CO	CUT-OFF ALARM	--
D	DROP THE FIRST AND SECOND RELAYS	8, 14
F	FUSE ALARM	--
LK	LOCK-UP RELAY	14
R	RING STATION	10, 14
T	TONE GENERATOR	4, 8
T1	TONE AUXILIARY NO. 1	8
W	TIMING RELAY	10, 14
W-	TIMING AUXILIARY NO. 1, 2, & 3	10, 14
Z	TIMING RELAY	10, 14
Z-	TIMING AUXILIARY NO. 1, 2, & 3	10, 14
	SD-80588-01	
	POWER CHARGE AND DISCHARGE	
CC	CHARGE CONTROL	--
CT	CHARGE CONTROL TRIP	--
	LIST OF RELAYS AND LOCATIONS ON OS DRAWINGS	
		755A P.B.X. 451-111







## TYPICAL TELEPHONE SET



**NOTE: SEE B.S.P 128.801 AND 950.701.01 FOR EXPLANATION OF SEQUENCE CHARTS  
AND DETACHED-CONTACT-SCHEMATIC DRAWINGS AND OPERATIONAL  
SKETCHES.**


**SD 66506-01 TONE, RINGING, ALARM AND COMMON TIMING**

SD 66507-01 STATION CIRCUIT

\* SD 66504-01 LINE,LINE SWITCH AND CALL ALLOTTER

## OPERATION OF LINE L-RELAY


OS-1  
755A PBX  
451-115






SD 66507-01 STATION CIRCUIT  
SD 66506-01 TONE,RINGING,ALARM AND COMMON TIMING  
SD 66611 -01 LINK AND LINK ALLOTTER  
**\* SD 66504-01 LINE,LINE SWITCH AND CALL ALLOTTER**

**SELECT LINK**

OS-2  
755A PBX  
451-116








\* SD66611-01 LINK AND LINK ALLOTTER  
SD66504-01 LINE, LINE SWITCH AND CALL ALLOTTER

REGISTER TENS DIGIT DIALED

OS-5  
755-A PBX  
451-119




\* SD6661I-01 LINK AND LINK ALLOTTER

OS-6  
OS-6  
755-A PBX  
45I-120  
REGISTERING UNITS DIGIT





SEQUENCE CHART



SD 66504-01 LINE LINE SWITCH AND CALL ALLOTTER  
 SD 66611-01 LINK AND LINK ALLOTTER  
 \* SD 66506-01 TONE, RINGING, ALARM AND COMMON TIMING

OS-8  
755 A PBX  
451-122

RECEIVING BUSY SIGNAL




SEQUENCE CHART AFTER LAST DIAL PULSE	
X A(LINK)	
SR	
C(LINK)	
X DC(LINK)	
X SW(LINK)	
X LK-	
B	E
EI	E2
SO	
MS	
X SEL MAG-	
X S & SI	
CI(LINK)	
X CO	
X HOLD MAG	
X PTS	
SR	
B	
X SEL MAG-	
S & SI	
LK-	
MS	E
EI & E2	

SD 666II-OI LINK AND LINK ALLOTTER  
\*SD 66504-OI LINE, LINE SWITCH AND CALL ALLOTTER

OPERATION OF SELECT MAGNET CALLED  
END OF LINK FOR CONNECTING TO IDLE LINE


OS-9  
755-A PBX  
451-123



\* SD 66506-01 TONE, RINGING, ALARM AND COMMON TIMING  
 SD 66504-01 LINE, LINE SWITCH AND CALL ALLOTTER  
 SD 66611-01 LINK AND LINK ALLOTTER

OS-10  
 75-A PBX  
 451-124

RINGING CALLED STATION



SEE OS-2 FOR CONTACTS OF CH- RELAYS


RELAYS OPERATED	RELAYS NORMAL	LINK SELECTED
CH1	CH2 AND CH3	LINK NO.1
CH1 AND CH2	CH3	LINK NO.1
CH1 AND CH3	CH2	LINK NO.3
CH2	CH1 AND CH3	LINK NO.2
CH2 AND CH3	CH1	LINK NO.2
CH3	CH1 AND CH2	LINK NO.3
NONE	CH1, CH2 AND CH3	NONE


USE "X" WIRING WHEN ONLY 2 LINKS ARE USED


#### INDICATION OF IDLE LINKS

SD 666II-OI LINK AND LINK ALLOTTER

OS-11  
755A PBX  
451-125









755-A P.B.X.


NORMAL TRUNK CIRCUIT




TRUNK CONNECTED TO KEY STATION



TRUNK IN A HOLD POSITION






PERSPECTIVE DRAWING OF CROSSBAR MECHANISM

PP9-537A  
10-51

VERTICAL UNIT  
NORMAL



UPPER CROSS POINT  
OF A PAIR OPERATED

UPPER CROSS POINT NORMAL,  
ARMATURE OPERATED



SELECTING  
BAR  
SELECTING  
FINGER

ARMATURE  
BAR




CROSSBAR SWITCH  
SELECTING MECHANISM


FIGS-5378  
10-51

## DIALING UNITS DIGITS

**NOTE: RELAY A RELEASES ON THE BREAK OF DIAL CONTACTS.**




**RELAY P1 WILL OPERATE IN SAME SEQUENCE as/ SEQUENCE B**



**The first pulse will be ODD. Pulses will alternate thereafter as/ number dialed.**

ODD



Digits Dialed

Relays  
Remaining Operated


Odd  
Pulses


Even  
Pulses

1-2-3-4-5-6  
7-8-9-0

1-3  
2-4  
2-5  
2-6  
5-6  
5-7, 0  
1-7, 0  
2-8, 0  
3-9, 0  
4-0, 0

## SET UP OF CHARGE RATE & CC RELAY

1. See Section B556.015 - 3.37 to 3.44 for setting charge rate.
2. CC Relay
  1. Block 1 top of (CT) relay open.
  2. Operate battery & ground key of 35F test set.
  3. Use jack on 35F test set 
  4. Non operate 21.5 volts.
  5. Operate 23. volts.



**OPTIONAL TRUNK SERVICE WIRING - 755A P.B.X.**

<u>T4</u>	<u>T3</u>	<u>T2</u>	<u>T1</u>


<u>T4</u>	<u>T3</u>	<u>T2</u>	<u>T1</u>

20

NL  
RS  
LO  
N

**ASSIGNMENT** \_\_\_\_\_

CROSS BAR SWITCH CONNECTION 755-A P.B.X.



M. B. T. CO. SO. DIV. PLANT  
INSTRUCTION DEPT.

FOR TAINING PURPOSES ONLY

## MICHIGAN BELL TELEPHONE COMPANY

## SOUTHERN DIVISION PLANT INSTRUCTION DEPARTMENT

755-A P.B.X. Cable Termination-Stations 20-29 &amp; 30-39

PAIR NO.	CA,PAIR		CONN.BLK. PAIR NO.	T.S.A. PCHG.NO.	STA. NO.
	TIP	RING			
1	White	Blue	1	1-2	20
	White	Orange	2	3-4	
3	White	Green	3	5-6	
4	White	Brown	4	7-8	
5	White	Slate	5	9-12	
6	White	Bl-Wh	6	1-2	
7	White	Bl-Or	7	3-4	
8	White	Bl-Gn	8	5-6	
9	White	Bl-Br	9	7-8	
10	White	Bl-Sl	10	9-12	
11	White	Or-Wh	11	1-2	21
12	White	Or-Gn	12	3-4	
13	White	Or-Br	13	5-6	
14	White	Or-Sl	14	7-8	
15	White	Gn-Wh	15	9-12	
16	White	Gn-Br	16	1-2	22
17	White	Gn-Sl	17	3-4	
18	White	Br-Wh	18	5-6	
19	White	Br-Sl	19	7-8	
20	White	Sl-Wh	20	9-12	
21	Red	Blue	21	1-2	23
22	Red	Orange	22	3-4	
23	Red	Green	23	5-6	
24	Red	Brown	24	7-8	
25	Red	Slate	25	9-12	

## MICHIGAN BELL TELEPHONE COMPANY

## SOUTHERN DIVISION PLANT INSTRUCTION DEPARTMENT

755-A P.B.X. Cable Termination-Stations 20-29 &amp; 30-39

PAIR NO.	CA. PAIR		CONN BLK PAIR NO.	T.S.A. PCHG. NO.	STA. NO.
	TIP	RING			
26	Red	Bl-Wh	1	1-2	25
27	Red	Bl-Or	2	3-4	
28	Red	Bl-Gn	3	5-6	
29	Red	Bl-Br	4	7-8	
30	Red	Bl-Sl	5	9-12	
31	Red	Or-Wh	6	1-2	
	Red	Or-Gn	7	3-4	
33	Red	Or-Br	8	5-6	
34	Red	Or-Sl	9	7-8	
35	Red	Gn-Wh	10	9-12	
36	Red	Gn-Br	11	1-2	26
37	Red	Gn-Sl	12	3-4	
38	Red	Br-Wh	13	5-6	
39	Red	Br-Sl	14	7-8	
40	Red	Sl-Wh	15	9-12	
41	Black	Blue	16	1-2	27
42	Black	Orange	17	3-4	
43	Black	Green	18	5-6	
44	Black	Brown	19	7-8	
45	Black	Slate	20	9-12	
46	Black	Bl-Wh	21	1-2	28
47	Black	Bl-Or	22	3-4	
48	Black	Bl-Gn	23	5-6	
49	Black	Bl-Br	24	7-8	
50	Black	Bl-Sl	25	9-12	
			26		

## MICHIGAN BELL TELEPHONE COMPANY

## SOUTHERN DIVISION PLANT INSTRUCTION DEPARTMENT

755-A P.B.X. Cable Termination-Stations 20-29 &amp; 30-39

PAIR NO.	CA. PAIR TIP	COLOR RING	CONN.BLK. PAIR NO.	T.S.A. PCHG.NO.	T.S.B. PCHG.NO.	TRK. NO.
51	Black	Or-Wh	1	Tk. } T 1 #1 } R 1		
52	Black	Or-Gn	2	Mis T 1 R 7		1
53	Black	Or-Br	3	Mis T 12 R 6		
54	Black	Or-Sl	4	Trk. } T 1 #2 } R 2		
55	Black	Gn-Wh	5	Mis T 2 R 8		2
56	Black	Gn-Br	6	Mis T 24 R 18		
57	Black	Gn-Sl	7	Trk. } T 1 #3 } R 2		
58	Black	Br-Wh	8	Mis T 3 R 9		3
59	Black	Br-Sl	9	Mis T 36 R 30		
60	Black	Sl-Wh	10	Trk. } T 1 #4 } R 2		
61	Red-Wh	Blue	11	Mis T 4 R 10		4
62	Red-Wh	Orange	12	Mis T 48 R 42		
63	Red-Wh	Green	13		Mis T 1 R 50	GRD. BATT.
64	Red-Wh	Brown	14		Mis T 2 R 51	GRD. BATT.
65	Red-Wh	Slate	15		Mis T 3 R 52	GRD. BATT.
66	Red-Wh	Bl-Wh	16		Mis T 4 R 53	GRD. BATT.
67	Red-Wh	Bl-Or	17		Mis T 5 R 54	GRD. BATT.
68	Red-Wh	Bl-Gr	18		Mis T 24 R 27	ALM. BELL.
69	Red-Wh	Bl-Br	19		Mis T 6 R 30	ALM. KEY
70	Red-Wh	Bl-Sl	20		Mis T 35 R 36	C.O. ALM.
71	Red-Wh	Or-Wh	21		Mis T 6 R 60	L.RG. MCH.



MICHIGAN BELL TELEPHONE COMPANY  
SOUTHERN DIVISION PLANT INSTRUCTION DEPARTMENT

755-A P.B.X. Cable Termination Stations 20-29 &amp; 30-39

PAIR NO.	CA.PAIR TIP	COLOR RING	CONN.BLK. PAIR	T.S.A. PCHG.NO.	T.S.B. PCHG.NO.	TRK. NO.
77	Red-Wh	Gn-Sl	1	Mis R 25	Mis T 15	Com
78	Red-Wh	Br-Wh	2	Mis R 26	Mis T 15	Rng
79	Red-Wh	Br-Sl	3	Mis R 27	Mis T 16	GRP
80	Red-Wh	Sl-Wh	4	Mis R 28	Mis T 16	CB2
81	Blk-Wh	Blue	5	Mis R 37	Mis T 17	Com
82	Blk-Wh	Orange	6	Mis R 38	Mis T 17	Rng
83	Blk-Wh	Green	7	Mis R 39	Mis T 18	GRP
84	Blk-Wh	Brown	8	Mis R 40	Mis T 18	CB3
85	Blk-Wh	Slate	9	Mis T 17 R 23		Sta
86	Blk-Wh	Bl-Wh	10	Mis T 29 R 35		Line
87	Blk-Wh	Bl-Or	11	Mis T 41 R 47		Lamps
88	Blk-Wh	Bl-Gn	12		Mis T 43 R 44	L 5-6 Con
89	Blk-Wh	Bl-Br	13		Mis T 45 R 46	L 7&8 Key
90	Blk-Wh	Bl-Sl	14		Mis T 37 R 38	#1 Con
91	Blk-Wh	Or-Wh	15		Mis T 39 R 40	#2 Sta
92	Blk-Wh	Or-Gn	16		Mis T 9 R 10	T-LP GRP
93	Blk-Wh	Or-Br	17		Mis T 12 R 12	Con Key
94	Blk-Wh	Or-Sl	18		Mis T 7 R 7	P.L. Key
95	Blk-Wh	Gn-Wh	19		Mis T 19 R 20	L-GD 20-23
96	Blk-Wh	Gn-Br	20		Mis T 21 R 22	L-GD 24-27
97	Blk-Wh	Gn-Sl	21		Mis T 23 R 28	L-GD 28-31
98	Blk-Wh	Br-Wh	22		Mis T 29 R 33	L-GD 32-35
99	Blk-Wh	Br-Sl	23		Mis T 34 R 41	L-GD 36-39
100	Blk-Wh	Sl-Wh	24		Mis T 11 R 49	RTX Spare Pr
101	White	Red	25			

## MICHIGAN BELL TELEPHONE COMPANY

## SOUTHERN DIVISION PLANT INSTRUCTION DEPARTMENT

## 755-A P.B.X. Cable Termination-Stations 20-29 &amp; 30-39

PAIR NO.	CA.PAIR TIP	COLOR RING	CONN.BLK PAIR NO.	T.S.B. PCHG.NO.	STA. NO.
02	Red-Black	Blue	1	1-2	30
03	Red-Black	Orange	2	3-4	
104	Red-Black	Green	3	5-6	
105	Red-Black	Brown	4	7-8	
106	Red-Black	Slate	5	9-12	
107	Red-Black	White	6	1-2	
108	Red-Black	Orange	7	3-4	
109	Red-Black	Green	8	5-6	31
110	Red-Black	Brown	9	7-8	
111	Red-Black	Bl-Sl	10	9-12	
112	Red-Black	White	11	1-2	
113	Red-Black	Green	12	3-4	32
114	Red-Black	Brown	13	5-6	
115	Red-Black	Or-Sl	14	7-8	
116	Red-Black	White	15	9-12	
117	Red-Black	Brown	16	1-2	
118	Red-Black	Gn-Sl	17	3-4	33
119	Red-Black	White	18	5-6	
120	Red-Black	Br-Sl	19	7-8	
121	Black-Or.	Sl-Wh	20	9-12	
122	Black-Or.	Blue	21	1-2	
123	Black-Or.	Orange	22	3-4	34
124	Black-Or.	Green	23	5-6	
125	Black-Or.	Brown	24	7-8	
126	Black-Or.	Slate	25	9-12	
			26		

## MICHIGAN BELL TELEPHONE COMPANY

## SOUTHERN DIVISION PLANT INSTRUCTION DEPARTMENT

755-A P.B.X. Cable Termination- Stations 20-29 &amp; 30-39

PAIR NO.	CA.PAIR	COLOR	CONN.BLK. PAIR NO.	T.S.R. PCNG.NO.	STA. NO.
	TIP	RING			
127	Black-Or.	Bl-Wh	1	1-2	35
128	Black-Or.	Bl-Or	2	3-4	
129	Black-Or.	Bl-Gn	3	5-6	
130	Black-Or.	Bl-Br	4	7-8	
131	Black-Or.	Bl-Sl	5	9-12	
132	Black-Or.	Or-Wh	6	1-2	
133	Black-Or.	Or-Gn	7	3-4	36
134	Black-Or.	Or-Br	8	5-6	
135	Black-Or.	Or-Sl	9	7-8	
136	Black-Or.	Gn-Wh	10	9-12	
137	Black-Or.	Gn-Br	11	1-2	
138	Black-Or.	Gn-Sl	12	3-4	
139	Black-Or.	Br-Wh	13	5-6	37
140	Black-Or.	Br-Sl	14	7-8	
141	Black-Gn.	Sl-Wh	15	9-12	
142	Black-Gn.	Blue	16	1-2	
143	Black-Gn.	Orange	17	3-4	
144	Black-Gn.	Green	18	5-6	
145	Black-Gn.	Brown	19	7-8	38
146	Black-Gn.	Slate	20	9-12	
147	Black-Gn.	Bl-Wh.	21	1-2	
148	Black-Gn.	Bl-Or.	22	3-4	
149	Black-Gn.	Bl-Gn	23	5-6	
150	Black-Gn.	Bl-Br	24	7-8	
151	Black-Gn.	Bl-Sl	25	9-12	39
152	White	Black	26		

\*152 Pair to be spare pair if 152 Pair is used only:

## MICHIGAN BELL TELEPHONE COMPANY

## SOUTHERN DIVISION PLANT INSTRUCTION DEPARTMENT

755-A P.B.X. Cable Terminal Stations 20-29 &amp; 30-39

PAIR NO.	CA.PAIR	COLOR	CONN.BLK. PAIR NO.	L1 LEADS FOR STA.#	T or B of	RES.UNIT	TRK. NO.
	TIP	RING			R		
152	Blk-Gr	Or-Wh	1	20-21	T 1T R 1B		1
153	Blk-Gr	Or-Gr	2	22-23	T 2T R 2B		1
154	Blk-Gr	Or-Br	3	24-25	T 3T R 3B		1
155	Blk-Gr	Or-Sl	4	26-27	T 4T R 4B		1
156	Blk-Gr	Gr-W	5	28-29	T 5T R 5B		1
157	Blk-Gr	Gr-Br	6	30-31	T 6T R 6B		1
158	Blk-Gr	Gr-Sl	7	32-33	T 7T R 7B		1
159	Blk-Gr	Br-Wh	8	34-35	R 8T R 8B		1
160	Blk-Gr	Br-Sl	9	36-37	T 9T R 9B		1
161	Blk-Br	Sl-Wh	10	38-39	T 10T R 10B		1
162	Blk-Br	Blue	11	20-21	T 11T R 11B		2
163	Blk-Br	Orange	12	22-23-	T 12T R 12B		2
164	Blk-Br	Green	13	24-25	T 13T R 13B		2
165	Blk-Br	Brown	14	26-27	T 14T R 14B		2
166	Blk-Br	Slate	15	28-29	T 15T R 15B		2
167	Blk-Br	Bl-Wh	16	30-31	T 16T R 16B		2
168	Blk-Br	Bl-Or	17	32-33	T 17T R 17B		2
169	Blk-Br	Bl-Gr	18	34-35	T 18T R 18B		2
170	Blk-Br	Bl-Br	19	36-37-	T 19T R 19B		2
171	Blk-Br	Bl-Sl	20	38-39	T 20T R 20B		2
172	Blk-Br	Or-Wh	21	20-21	T 21T R 21B	3	
173	Blk-Br	Or-Gr	22	22-23	T 22T R 22B	3	
174	Blk-Br	Or-Br	23	24-25	T 23T R 23B	3	
175	Blk-Br	Or-Sl	24	26-27	T 24T R 24B	3	
176	Blk-Br	Gr-Wh	25	28-29	T 25T R 25B	3	

## MICHIGAN BELL TELEPHONE COMPANY

## SOUTHERN DIVISION PLANT INSTRUCTION DEPARTMENT

## 755-A P.B.X. Cable Terminals Stations 20-29 &amp; 30-39

NO.	CA.PAIR	COLOR	CONN.BLK. PAIR NO.	L1 LEADS FOR STA.#	T OR B OF	TRK. NO.
	TIP	RING			RES.UNIT	
177	Blk-Br	Gr-Br	1	30-31	T 26 T R 26 B	3
178	Blk-Br	Gr-Sl	2	32-33	T 27 T R 27 B	3
179	Blk-Br	Br-Wh	3	34-35	T 28 T R 28 B	3
180	Blk-Br	Br-Sl	4	36-37	T 29 T R 29 B	3
181	Blk-Br	Sl-W	5	38-39	T 30 T R 30 B	3
182	Blk-Sl	Blue	6	20-21	T 31 T R 31 B	4
183	Blk-Sl	Orange	7	22-23	T 32 T R 32 B	4
184	Blk-Sl	Green	8	24-25	T 33 T R 33 B	4
185	Blk-Sl	Brown	9	26-27	T 34 T R 34 B	4
186	Blk-Sl	Slate	10	28-29	T 35 T R 35 B	4
187	Blk-Sl	Bl-Wh	11	30-31	T 36 T R 36 B	4
188	Blk-Sl	Bl-Or	12	32-33	T 37 T R 37 B	4
189	Blk-Sl	Bl-Gr	13	34-35	T 38 T R 38 B	4
190	Blk-Sl	Bl-Br	14	36-37	T 39 T R 39 B	4
191	Blk-Sl	Bl-Sl	15	38-39	T 40 T R 40 B	4
192	Blk-Sl	Or-Wh	16	L1 Leads	T 41 T R 41 B	
193	Blk-Sl	Or-Gr	17	FOR	T 42 T R 42 B	
194	Blk-Sl	Or-Br	18	Stations	T 43 T R 43 B	
195	Blk-Sl	Or-Sl	19	Provided	T 44 T R 44 B	
196	Blk-Sl	Gr-Wh	20	With	T 45 T R 45 B	
197	Blk-Sl	Gr-Br	21	Local	T 46 T R 46 B	
198	Blk-Sl	Gr-Sl	22	Line	T 47 T R 47 B	
199	Blk-Sl	Br-Wh	23	Lamps	T 48 T R 48 B	
200	Blk-Sl	Br-Sl	24		T 49 T R 49 B	
201	Blk-Sl	Sl-Wh	25		T 50 T R 50 B	
202	White	Black	26		SPARE	

Prepared By:  
J. C. Roodvoets  
Plant School  
Grand Rapids

Form 755-7

WIRE AND EQUIPMENT REQUIRED FOR  
EACH OPTIONAL FEATURE - 755 - PBX

Optional Feature	Extra Line Pick-Up	Using Seperate Key
	SD 66504-012	8 - 9 - 12
Drawing Nos.	T 66504 - 14	Fig. Nos. 1, 3 & 4


**DWG. 755-2**      **EQUIPMENT REQUIRED**

Quan. Item Code No. Quan. Item Code No. Quan. Item Code No.

1	Relay	U-612					
1	Key	6017G 551 P.B.					

Part No. Ga. Cond. Type : . Ga. Cond. Type Color

P-467477	22	Single	SCB		P-324442	22	Single	DCL	Red
P-324382	22	Single	DCL	R-Or.	P-324444	22	Single	DCL	R-Wh
P-324422	22	Single	DCL	R-Bk-Or					
P-324383	22	Single	DCL	R-Gr.					
P-324443	22	Single	DCL	Black					
P-324445	22	Single	DCL	Bk-Wh.					
P-324395	22	Single	DCL	R-Gr-Wh					
P-324385	22	Single	DCL	R-Sl.					
P-324398	22	Single	DCL	R-Br-Wh					
P-324425	22	Single	DCL	R-Bk-Sl Gr.					
P-364404	22	2-Cond	DCL	(Gr-Wh					
P-364401	22	2-Cond	DCL	(Bl. (Bl-Wh					
P-364403	22	2-Cond	DCL	(Sl. (Sl-Wh					



LAMP AND WINK HOLD CIRCUIT FOR 755 PBX

EXTRA LINE PICKUP PATTERN USING SEPARATE KEY ON  
KEY STATION (WITHOUT LAMPS ON LOCAC)

22 GA SWED WIRE	Lead Design.	SW HOLD RELAY	TS "A" OR "B"	L RELAY	Hold MAG.	CO RELAY	
(S)	T	5T					
(R)	B-W	2T		R			
(G)	R-G	8T		G			
(L)	R-B	2B		L			
(K)	R-O	18-10T		K			
(C)	G-W	6T		1B			
(P)	G-W	3T		9T			
(J)	S	4T		1B *			
(I)	S-W	1T		9T *			
(U)	R-W	9T		1B			
(V)	B-G	5B					
(E)	B-S	6B					
(Z)	R-B	3B					
(N)	B-H-W	7B					
(O)	B-H-S	9B					
(P)	B-H-S	4B		7T			
(Q)	O-G	7B			5B *	ONLY WHEN STA 1570 B.C.	
(R)	O	8B				7B *	PICKED UP (NOT CO LINE)
(S)	G						
(W)	G-W						
(R)	R-G						
(G)							


\* - LINE OFF STA TO BE PICKED UP OR CO LINE  
† - TRAP TO OTHER SW RELAYS

T 66504 - 33 DUE 4  
T " " - 34 " 22  
SD " .012 .121

Wise

**POWER FAILURE OPTION FOR 755 PBX**


**227A KEY TELEPHONE UNIT**



**THIS OPTION TRANSFERS TRUNKS TO PREDETERMINED STATIONS IN A POWER FAILURE CONDITION**

**EQUIPMENT NOTES:**

- 201. THIS KEY TEL UNIT IS DESIGNED FOR USE PRIMARILY IN KEY TEL SYSTEM NO. SA.30-69226-01, J60022
- 202. THIS KEY TEL UNIT IS 7 MODULES + 3 LINE WIRE.



3 PAIR PER TRUNK.

STRAP 24V FROM  
PHG 40, LOWER WINDING  
STRAPPED INTERNALLY  
WITH PHG 10


W-100  
9-7-66

Note 1 Sec 1 5A-KTU shall be mounted in a 105A app. former to be mounted as closely as possible to the R.B.X.


Note 2 Connect leads to terminals 15, 17, 20 & 28 as follows -

Line Voltage	Circuit	Terminals	Connect G lead
110	1	1	D
115	1	1	C
120	1	2	D
125	1	3	C


SA-KTU (LAMP RELAY)



To trunk  
lamps No. 1  
on sta. tel.  
sets.



These leads to be  
209a.A.M wire and to  
be kept as short as  
possible.



Connect to 110-125 V.  
50-60 cycle supply.

Note 2.


- (A) Installations with up to 24 trunks do not require an auxiliary power supply.
- (B) Installations with from 24-30 trunk lamps require one transformer per installation.
- (C) Installations with from 37-80 trunk lamps require one transformer per trunk, and relay per trunk; one transformer for trunks 3 and 4, the transformer for trunks 5 and 6,

Auxiliary 10 Volt A.C.  
Power Supply  
Transformer illuminated sets:  
755 PBT using illumination 2  
Copy of SKEO issue 2  
J.H. Keast

Fig. 24. 34. & 44.

Auxiliary 10 Volt A.C.  
Power Supply  
Transformer illuminated sets:  
755 PBT using illumination 2  
Copy of SKEO issue 2  
J.H. Keast

## NOTES



SURFACE WRITING DRAWING - KEY STATION WITH LINE LAMPS  
755 P.B.X. OPTIONAL EQUIPMENT  
REFERENCE T-66504-14 FIGS. 1, 5, 6 & 7

755 P.B.X. OPTIONAL EQUIPMENT  
SURFACE WIRING DRAWING - KEY STATION - EXTRA NE PICK-UP - USING SPARE TRUNK KEY.

REFERENCE  
T-66504 - 14  
FIGS 1,3 & 4

*NOTES —*

- (A) Wiring to be used when a station is to be picked-up.
  - (B) Wiring to be used when a C.O. Trunk is to be picked-up.  
Use pair 94.
  - (PK) Wiring to be used when station to be picked up is a key station. Not used for keyless stations or C.O. trunk pick-ups.

U-612 Routh Co. W. BURDICK  
U-182 " " SOUTHERN DIV.

SOUTHERN DIVISION PLANT SCHOOL  
FOR TRAINING PURPOSES ONLY  
J.C. ROODVOETS 10-28-49

