


# Outdoor Telephone Dial Version



**N.B. - If a louder ringer is required, disconnect the 6-L ringer and connect a type 392-J Subscriber set to terminals "L-1" and "C".**