

## **ITT Frequency Ringer Codes**

HA1: 33-1/3 cps.

HA2: 50 cps.

HA3: 66-2/3 cps.

HA4: 16-2/3 cps.

HA5: 25 cps.

HB1: 30 cps.

HB2: 42 cps.

HB3: 54 cps.

HB4: 66 cps.

HB5: 16 cps.

HC1: 20 cps.

HC2: 60 cps.

HC3: 30 cps.

HC4: 40 cps.

HC5: 50 cps.