



- NOTES
1. WHEN USED AS BATTERY CHARGER, DISCONNECT STRAP SHOWN THUS —x—x—
  2. ALL WIRING TO BE 7/029 UNLESS OTHERWISE SPECIFIED.
  3. FUSES 2,3&4 ARE STRAPPED ON FUSE PANEL ASSEMBLY, TOGETHER WITH R1.

SUPERSEDES GBW 15480

|                       |       |            |                |   |         |
|-----------------------|-------|------------|----------------|---|---------|
|                       |       |            |                | 7.5 AMP.<br>BATTERY ELIMINATOR<br>FOR 120A AND 135A TYPE<br>P.A.B.X's |         |
|                       |       |            |                | (33119)   | 18-3-60 |
| AMENDMENT PARTICULARS |       | ISSUE DATE | APPD.          | REF-22LFE1878A  |         |
|                       |       | SIZE: S    |                | <b>GBW 15490</b>  |         |
| NZPO                  | DRAWN | CHECKED    | WIRING CIRCUIT |   |         |