

BELL SYSTEM PRACTICES
Station Installation and Maintenance

SECTION C65.514
Issue 1, 7-24-36
AT&T Co. Standard

ORDER TURRET No. 1
CONNECTIONS

1. GENERAL

1.01 This section covers the manual and dial connections for Order Turret No. 1 and the desk stands which are used with this turret.

1.02 When adding the 3A or 4A varistor to an existing turret, remove existing wires between T and LT terminals of the induction coil and telephone set terminals GN and Y. Run a pair of wires from terminals T and LT of induction coil to the varistor and run another pair of wires from the varistor to telephone set terminals GN and Y.




Fig. 1—50E Desk Stand (Dial only)




Fig. 2—40AL Desk Stand or Equipment (Manual only)




Fig. 3—Order Turret No. 1 Manual and Dial