

COMPONENTS AND COLOR SELECTION

- 1.01** For component and color selection information on 1A/2A, 1C/2C, and 1E-type coin telephone sets or 1D/2D coin telephone sets, refer to Sections 506-410-400 and 506-410-401, respectively.

TABLE A
COMPONENT AND COLOR SECTION
(1A/2A-TYPE SETS)

COIN TEL SET	FRONT COVER		DIAL AND HOUSING		DIAL	NUMBER PLATE ASSY	INFORMATION PLATE	HANDSET
	COVER UNIT ASSY (MD)	COIN COVER UNIT *	DIAL AND HOUSING ASSY (MD)	COIN DIAL UNIT *				
1A1-03 (Black)	819054032 (P-90E403)	70A1-03	841317241	60A1-44 60A2-44	8WA or 8W (MD)	818418527		
1A1-44 (Chrome)	819054446 (P-90E444)	70A1-44	819042748 (P-90D274)	60A1-44 60A2-44				
1A1-51 (Moss Green)	819054511 (P-90E451)	70A1-51		60A1-44 60A2-44				
1A2-03 (Black)	819055039 (P-90E503)	71A1-03	840346977	61A1-44	70A (MD) or 70B	840156319	840156319	G3AH-52† G3AK-52† G3AHF-52† G3AKF-52† G13-Type‡
1A2-44 (Chrome)	819055443 (P-90E544)	71A1-44	840346977	61A1-44	70A (MD) or 70B	840156319	840156319	G3AH-52† G3AK-52† G3AHF-52† G3AKF-52† G13-Type‡
1A2-51 (Moss Green)	819055518 (P-90E551)	71A1-51	840346977	61A1-44	70A (MD) or 70B	840156319	840156319	G3AH-52† G3AK-52† G3AHF-52† G3AKF-52† G13-Type‡
2A1-67 (Brushed Stainless)				61A1-44	8WA or 8W (MD)	818720526		
2A2-67 (Brushed Stainless)				61A1-44	70A (MD) or 70B			
					35T3A			

* These coin cover unit and coin dial unit codes are for ordering information to obtain the unit, wired, tested, and equipped for the correct mode of operation. Since the units may be field converted from one type to another, maintenance, and installation should be based on the first three (3) characters of the code only. It is important therefore to ensure that the unit being used is wired properly and that the coin cover unit has the proper information plate and instruction cards for the type of service with which it is being used. All rotary coin cover units are equipped with 8WA dials and all TOUCH-TONE coin covers units are equipped with 70A (MD) or 70B dials.

† G3AHF-52 and G3AKF-52 are optional flame retardant handsets and cords that can replace the G3AH-52 and G3AK-52 respectively. The G3AK and G3AKF are equipped with a moisture resistant transmitter barrier and special transmitter cap.

‡ A G13D amplified handset can be used. Refer to Section 501-211-102 for complete information.

TABLE A (Contd)
COMPONENT AND COLOR SECTION
(1A/2A-TYPE SETS)

HOUSING AND MTG PLATE ASSY	CHUTE-TOTALIZER	COIN CHASSIS	COIN RELAY AND HOPPER ASSY	RETURN CHUTE ASSY	COIN RETURN ASSY	COIN RECP RAIL	CASH COMPT. DOOR
818512036 (P-85A203)	811554286 (P-15E428) Consist of 20A Chute 811555796 (P-15E579) Totalizer	840693634 with DF Oscillator	1AA Coin Relay Consist of 1A Coin Relay and 811557172 Coin Hopper Assembly	811557305 (Current return chute assemblies are made of plastic instead of diecasting)	812165462	1B	2A-03 or 2B-03 (Optional)
818512444 (P-85A244)							2A-44 or 2B-44 (Optional)
818512519 (P-85A251)							2A-51 or 2B-51 (Optional)
818512036 (P-85A203)							2A-03 or 2B-03 (Optional)
818512444 (P-85A244)							2A-44 or 2B-44 (Optional)
818512519 (P-85A251)		2A-51 or 2B-51 (Optional)					
						1D	5A-67

TABLE B
COMPONENT AND COLOR SECTION
(1C/2C/1E-TYPE SETS)

COIN TEL SET	MODE OF OPERATION	FRONT COVER		DIAL AND HOUSING			NUMBER PLATE ASSY	INFORMATION PLATE	HANDSET				
		COVER UNIT ASSY (MD)	COIN COVER UNIT *	DIAL AND HOUSING ASSY (MD)	COIN DIAL UNIT	DIAL							
1C1-03 (Black)	CF	819054032	70A1-03	841317241 or 819042748 (P-90D274)	60A1-44	8WA or 8W (MD)	818418527	840156319 for Coin First	G3AH-52† G3AK-52† G3AHF-52† G3AKF-52 † G13-Type‡				
1C1-44 (Chrome)	CF	819054446	70A1-44		60A2-44								
	DTF	(P-90E444)	70A2-44		60A1-44								
1C1-51 (Moss Green)	CF	819054511	70A1-51		60A2-44								
	DTF	(P-90E451)	70A2-51	60A2-44									
1C2-03 (Black)	CF	819055039	71A1-03	840346977 (70A Dial)	61A1-44	70A (MD), or 70B, 35T3A (MD)	840156319 for Coin First			840156327 for Dial Tone First (Used on 1C-and 2C-Type sets only)	G3AH-52† G3AK-52† G3AHF-52† G3AKF-52 † G13-Type‡		
	DTF	(P-90E503)	71A2-03	61A2-44									
1C2-44 (Chrome)	CF	819055443	71A1-44	819042755 (P-90D275)	61A1-44								
	DTF	(P-90E544)	71A2-44	61A2-44									
1C2-51 (Moss Green)	CF	819055518	71A1-51	(35T3A Dial)	61A1-44								
	DTF	(P-90E551)	71A2-51	61A2-44									
2C1-67 (Brushed Stainless)	CF			841317241 or 819042748 (P-90D274)	60A1-44	8WA or 8W (MD)	818720526					840156327 for Dial Tone First (Used on 1C-and 2C-Type sets only)	G3AH-52† G3AK-52† G3AHF-52† G3AKF-52 † G13-Type‡
	DTF			841317258 or 840152227	60A2-44								
2C1-84 (Bronze)	CF			840346977	61A1-44			70A (MD), 70B, 35T3A (MD)					
	DTF			(P-90E544)	71A2-44			61A2-44					
2C2-67 (Brushed Stainless)	CF			819042755	61A1-44	70A (MD), 70B, 35T3A (MD)	818720039	840156327 for Dial Tone First (Used on 1C-and 2C-Type sets only)	G3AH-52† G3AK-52† G3AHF-52† G3AKF-52 † G13-Type‡				
	DTF			840347173	61A1-84								
2C2-84 (Bronze)	CF			840157580	61A1-84					35T3A (MD)			
	DTF			(P-90E551)	71A2-51					61A2-84			
1E1-03 (Black)	Dial Post Pay	840658033	70A5-03	841317241 or 819042748 (P-90D274)	60A2-44	8WA or 8W (MD)	818418527			840156087	G3AH-52† G3AK-52† G3AHF-52† G3AKF-52 † G13-Type‡		
1E1-44 (Chrome)		840658447	70A5-44										
1E1-51 (Moss Green)		840658512	70A5-51										
1E3-03 (Black)	Manual Post Pay	840659031	70A4-03	841317266 or 812366516 (P-23F651)	60A4-44	840994727 Apparatus Blank Assembly	840156087						
1E3-44 (Chrome)		840659445	70A4-44	Housing Assembly									
1E3-51 (Moss Green)		840659510	70A4-51										

* These coin cover unit and coin dial unit codes are for ordering information to obtain the unit, wired, tested, and equipped for the correct mode of operation. Since the units may be field converted from one type to another, maintenance, and installation should be based on the first three (3) characters of the code only. It is important therefore to ensure that the unit being used is wired properly and that the coin cover unit has the proper information plate and instruction cards for the type of service with which it is being used. All rotary coin cover units are equipped with 8WA dials and all TOUCH-TONE coin cover units are equipped with 70A (MD) or 70B dials.

† G3AHF-52 and G3AKF-52 are optional flame retardant handsets and cords that can replace the G3AH-52 and G3AK-52 respectively. The G3AK and G3AKF are equipped with a moisture resistant transmitter barrier and special transmitter cap.

TABLE B (Contd)
COMPONENT AND COLOR SECTION
(1C/2C/1E-TYPE SETS)

HOUSING AND MTG PLATE ASSY	CHUTE-TOTALIZER	COIN CHASSIS	COIN RELAY AND HOPPER ASSY	RETURN CHUTE ASSY	COIN RETURN ASSY	COIN RECP RAIL	CASH COMPT. DOOR
818512036 (P-85A203)	20A1A Consist of 20A Chute and 1A Totalizer	31A with DF Oscillator (31A2 Coin Chassis is available wired and tested for DTF service)	1AA Coin Relay Consist of 1A Coin Relay and 811557172 (P-15E717) Coin Hopper Assembly	811557305 (Current return chute assemblies are made of plastic instead of diecasting)	812165462	1B	2A-03 or 2B-03 (Optional)
818512444 (P-85A244)							2A-44 or 2B-44 (Optional)
818512519 (P-85A251)							2A-51 or 2B-51 (Optional)
818512036 (P-85A203)							2A-03 or 2B-03 (Optional)
818512444 (P-85A244)							2A-44 or 2B-44 (Optional)
818512519 (P-85A251)							2A-51 or 2B-51 (Optional)
							5A-67
	840152219	1D	5A-84				
	812165462		5A-67				
	840152219		5A-84				
840656037	20A10A Consist of 20A Chute and 10A Totalizer		30B with DF Oscillator	51A or 50A (MD) Hopper Assembly	812165462	1B	2A-03 or 2B-03 (Optional)
840656441		2A-44 or 2B-44 (Optional)					
840656516		2A-51 or 2B-51 (Optional)					
840657035		50B Hopper Assembly		2A-03 or 2B-03 (Optional)			
840657449				2A-44 or 2B-44 (Optional)			
840657514				2A-51 or 2B-51 (Optional)			

‡ A G13D amplified handset can be used. Refer to Section 501-211-102 for complete information.

TABLE C
COMPONENTS AND COLOR SELECTION
(1D/2D-TYPE SETS)

COIN TEL SET	COIN COVER UNIT	COIN DIAL UNIT*	DIAL†	NUMBER PLATE ASSY	INFOR- MATION PLATE	HANDSET (NOTE)
1D1-03 (Black)	70A3-03	60A3-44	8W (MD) or 8WA	818418527	840156327	G3AH, G3AK, G3AHF, or G3AKF
1D1-44 (Chrome)	70A3-44					
1D1-51 (Moss Green)	70A3-51					
1D2-03 (Black)	71A3-03	61A3-44	70A (MD) or 70B			
1D2-44 (Chrome)	71A3-44					
1D2-51 (Moss Green)	71A3-51					
2D1-67 (Brushed Stainless)		60A3-44	8W (MD) or 8WA	818720526		
2D1-84 (Bronze)				818720039		
2D2-67 (Brushed Stainless)		61A3-44	70A (MD) or 70B			
2D2-84 (Bronze)						

Note: A G13D amplified handset can be used with a 1D/2D coin telephone set. Refer to Section 501-211-102 for complete information.

* These coin cover unit and coin dial unit codes are ordering information to obtain the unit, wired, tested, and equipped for the correct mode of operation. Since the coin-first and dial-tone-first coin cover units and coin dial units shown in Table B (Part 1-5) of the manual may be field converted from one type to another, maintenance, and installation should be based on the first three (3) characters of the code only. It is important therefore to ensure that the unit being used is wired properly and that the coin cover unit has the proper information plate and instruction cards for the type of service with which it is being used. All rotary coin cover units are equipped with 8W (MD) or 8WA dials and all TOUCH-TONE coin cover units are equipped with 70A (MD) or 70B dials.

† 70A (MD) dials manufactured before May, 1977 do not meet the same manufacturing electrical requirements as the D-type set. Upon conversion to D-type sets or during coin cover unit or coin dial unit replacement check the date of the dial on the dial front face-plate. Do not use a pre-May, 1977 70A dial unless the later vintage is not readily available.

TABLE C (Contd)
COMPONENTS AND COLOR SELECTION
(1D/2D-TYPE SETS)

CHUTE	COIN CHASSIS	COIN RELAY AND HOPPER ASSY	RETURN CHUTE ASSY	COIN RETURN ASSY	COIN RECEPTACLE	CASH COMPT DOOR
20A47A (MD) or 20A47A2 Consists of a 20A Chute and a 47A (MD) or 47A2 Signal	32A	1AA Consists of a 1A Coin Relay and 811557172 Coin Hopper Assy	811557304	812165462	1B	
						5A-67
				840152219		5A-84
				812165462	1D	5A-67
				840152219		5A-84