SERVICE

203A, B, C, D, E, AND F HAND TELEPHONE SETS

1. GENERAL

- 1.01 This section contains connection information for 203-type hand telephone set formerly found in Sections 502-311-400 and 502-311-401 which are hereby canceled.
- 1.02 The 203A, B, and C types differ from the 203D, E, and F types only in the internal wiring arrangements as furnished.
- 1.03 The 203A and C differ from the 203B, and the 203D and F differ from the 203E, only in the type of dial number plate.

TABLE A
LINE AND RINGER CONNECTIONS
685A OR 686A SUBSET USED WITH
203A, B, C, D, E, OR F HAND TELEPHONE SETS

WIRE OR LEAD	COLOR	RING PARTY	TIP PARTY (NOTE 1)	NEGATIVE	POSITIVE
				RING STATION (NOTE 1)	
				1 AND 5	3 AND 6
Ringer Leads (Note 2)	R BK S S-R	L2 G K* 1	L2 G K* 1	G G A* K*	L2 L2 A* K*
426A Tube Leads (3 elements) (686A only)	BK Y R			K* L2 G	K* G L2

^{*} Terminal on network.

Notes:

- 1. Reverse tip and ring for tip party service.
- 2. To silence ringer permanently, connect (R) and (BK) ringer leads to K on the terminal strip.




Fig. 1—203A, B, C, D, E, and F Hand Telephone Sets, Connections used with 685A Subscriber Set

TABLE B ASSOCIATED APPARATUS

CLASS OF SERVICE	SUBSCRIBER SET	
Individual Lines 2-Party Flat Rate* 2-Party Message Rate (Ring Party Only)* 4-Party Semiselective Multiparty Divided Code Regular PBX Stations 750A and 755A Keyless Stations	685A	
4-Party Full Selective 8-Party Semiselective	686A	

^{*} No message rate or tip-party identification can be provided for tip-party station.

TABLE C
61N FILTER CONNECTIONS
(NOTE)

FILTER LEADS	FILTER LEAD TERMINATIONS			
BK	BK of dial			
Y	Y of dial			
R	BK of line switch			

Note: The 203-type sets are arranged for, but not equipped with, a 61N filter for radio-frequency suppression. When this filter is required, remove the dial cord between Y of the dial and BK of the line switch, connect filter as shown in table.

TABLE D COMBINATION OF APPARATUS

HAND	COMPONENTS						
TEL SET CODE	HANDSET	HANDSET MOUNTING	DIAL OR APPARATUS BLANK	TYPE MOUNTING CORD	TYPE HANDSET CORD		
MODIFIED							
203B-3E 203E-3E	E1E-3	D6-3	50J-3 94A-3	D6			
203B-3F 203E-3F	F1A-3 F1G-3						
203B-3F 203E 3F	F4A-3						
203B-3E 203E-3E	E1E-3		4H or 5H		H-3		
203B-3F 203E-3F	F1A-3 F1G-3		5H or 6A	D6 D9			
203B-3F 203E-3F	F4A-3		. 6A				