STATION SETS — MAGNETO SELECTION FOR GENERAL USE

1.00 INTRODUCTION

This section covers, in table form, the selection of magneto station sets for general use.

2.00 SELECTION

TABLE A - SELECTION OF MAGNETO SETS FOR GENERAL USE

Class of Service	Wall Set	Combined Tel Set	Associated Sub. Set	Hand Tel Set	Desk Stand	Associated Sub. Set
Individual Line, PBX and Nonselective Code Ringing on rural lines having eight or less stations and a loop resistance from central office to any sta- tion of 800 ohms or less	417AH	307A 357A	299F or D-176680	202H 211E 213E* 215A*	151AL 152AB	415H
Nonselective Code Ringing on rural lines having more than eight stations or a loop resist- ance from central office to any station of more than 800 ohms	417P	307A 357A	299F	202H 211E 213E* 215A*	151AL 152AB	400A or 400K
2-Party Selective 4-Party Semiselective Regular Stations	417BS	307A 357A	299F or D-176680	202H 211E 213E* 215A*	151AL 152AB	415E
2-Party Selective 4-Party Semiselective Stations with Inductive Noise	417CD	307A 357A	299F or D-176680	202H 211E 213E* 215A*	151AL 152AB	400CD or 415CD
4-Party Selective Regular Stations	417BS	309A	299F or D-176680	202H 211E 213E* 215A*	151AL 152AB	415E
4-Party Selective Stations with Inductive Noise	417CD	309A	299F or D-176680	202H 211E 213E* 215A*	151AL 152AB	400CD or 415CD
Divided Code	417CD	307A 357A	299F or D-176680	202H 211E 213E* 215A*	151AL 152AB	400CD or 415CD

^{*} For use where more than one hand telephone set is used with one subscriber set.

2.01 The 357A telephone set is produced in ivory as well as black. The 307A telephone set is produced in the colors shown in Table B.

TABLE B
COLOR CHART FOR 307A TELEPHONE SET

Code				
307A — 50A				
307A — 51A				
307A — 52A				
307A — 53A				
307A — 54A				
307A — 55A				
307A — 56A				
307A — 57A				

TABLE C-TRANSMISSION ZONING CHART FOR MAGNETO OFFICES

Zone	Class of Service	1st Choice Equipment				Alternate Equipment						
		Handset Stations		Nonhandset Stations		Handset Stations			Nonhandset Stations			
		Type Handle	Trans Unit	Rec Unit	Trans /Unit	Rec /Unit	Type Handle	Trans Unit	Rec Unit	Trans /Unit	Rec /Unit	
М1	A11	F1				605/74		F1	F1	HA1	635/F1	706/HA1
M2	A11		F1	HA1	635/F1	706/HA1	F4 or F5	Т1	U1	None	None	

Note: Use an F5 rather than F4 handset when a 4-conductor cord with an F-type handset is required.