

1A AND 1A1 SPEAKERPHONE SYSTEMS

CONNECTIONS


1.00 GENERAL

The wiring diagrams shown in this section cover the connections between speakerphone components. Refer to Table A, Index for Speakerphone Components.

- For additional connection information, refer to SD-69255-01.
- For internal wiring of telephone sets, refer to the appropriate C Section.

TABLE A
INDEX FOR SPEAKERPHONE COMPONENTS

Telephone Sets and Components		Fig.
592 type (manufactured prior to November, 1954)		1 and 2
592 type (manufactured after November, 1954)		3 and 4
656A transmitter		5
Key telephone set conversions		Table B
211 N/P telephone set		6
500 R/S telephone set		7
511 C/D telephone set		8
565G telephone set		9
565H telephone set		10
565L telephone set		11
566MB telephone set		12
600A and B or 601A and B telephone sets with 661A transmitter unit		13
KS-14964 control unit with KS-14990 amplifier	schematic	14
KS-14964, List 2 control unit with KS-14990 amplifier		15
KS-14964, List 3 control unit with KS-14990, List 2 amplifier		16



**Fig. 1 — 1A and 1A1 Speakerphone System — 592-type Telephone Set
Manufactured Prior to November, 1954**




Fig. 2 — 592-type Telephone Set Manufactured Prior to November, 1954




Fig. 3 — 1A and 1A1 Speakerphone System — 592-type Telephone Set Manufactured After November, 1954




Fig. 4 — 592-type Telephone Set Manufactured After November, 1954




Fig. 5 — 656A Transmitter Unit

TABLE B
1A AND 1A1 KEY TELEPHONE SET CONVERSIONS
 (With and Without Station Busy Lamps)

Tele- phone Set	Station Busy LP Circuit	Key Tel Sys	Switch			Hold Key		Dial Leads		Cord Conductors		M1W Cord
			SL-W	SL-GN	SL-Y	Y	Y-BK	Y	Y	OR-R	OR	
565HA 565HB 565LA 565LB	No	1A	SG	L2*	N	R	M	ON	ON 1	N	†	—
		1A1	1B	N	R	M	N	ON	ON 1	R	N	—
	Yes	1A	SG	L2*	N	R	M	ON	ON 1	N	L2*	—
		1A1	1B	L2*	R	M	N	ON	ON 1	R	L2*	G to N*
565GA 565GB	No	1A	SG	L2*	N	—	—	ON	‡	N	M	—
		1A1	1B	M	N	—	—	ON	‡	N	M	—
	Yes	1A	SG	L2*	N	—	—	ON	‡	N	L2*	—
		1A1	1B	L2*	N	—	—	ON	‡	N	L2*	G to M*

* On network.

† Tape and store.

‡ Terminal not provided—connect to OR-W conductor of mounting cord with D161488 connector, or equivalent.






Fig. 6 — 211N/P Telephone Set



* Terminal on network.

Note 1: KS-14964, L3 only. Terminate loudspeaker lead on terminal 14. If loudspeaker operates gain switching circuit, move lead to terminals A, B, or C, respectively.


Fig. 7 — 500R/S Telephone Set




* Terminals on network.

Note 1: KS-14964, L3 only. Terminate loudspeaker lead on terminal 14. If loudspeaker operates gain switching circuit, move lead to terminals A, B, or C, respectively.


Fig. 8 – 511C/D Telephone Set



Page 8



565L CONNECTIONS



Note 1: KS-14964, L3 only. Terminate loudspeaker lead on terminal 14. If loudspeaker operates gain switching circuit, move lead to terminals A, B, or C, respectively.

* Cord conductors taped and stored in set.

† Terminals on network.

‡ See conversion Table B.

Fig. 11 — 565L Telephone Set




Fig. 12 — 566MB Telephone Set




Fig. 13 – 600A and B or 601A and B Telephone Sets
with 661A Transmitter Unit

661A TRANSMITTER INTERNAL LEAD CONNECTIONS		
Lead Desig	Lead Color	600A and B or 601A and B
T1	OR-GN	RR of Network
R1	OR-R	1 of Ringer TS
P3	OR-W	BB of Dial
P4	OR-BL	W of Dial
LK	OR-BK	L1 of Network
AG	OR	G of Network
A1	Y	4 of Ringer TS

Note 1: KS-14964, L3 only. Terminate loudspeaker lead on terminal 14. If loudspeaker operates gain switching circuit, move lead to terminals A, B, or C, respectively.

Note 2: Third KS-16671, L1 plug and KS-16690, L1 connector on 600A and B telephone sets; fifth KS-16671, L1 plug and KS-16690, L1 connector on 601A and B telephone sets.



Page 13





Fig. 15 - KS-14964, List 2 Control Unit with KS-14990 Amplifier



**Fig. 16—KS-14964, List 3 Control Unit with
KS-14990, List 2 Amplifier**