



## How to use your LOGIC 10\* key telephone set




*Northern Electric*  
COMPANY LIMITED

\*Trademark of Northern Electric Company Limited

## LOGIC 10

Your LOGIC 10 key telephone set is a pleasure to look at and a pleasure to operate. With it you can have access to up to nine lines and optional features such as add-on, intercom, exclusion, paging, etc. You can also have options added to your LOGIC 10 set to make using it even more of a pleasure. A headset for handsfree, private telephone conversations, or a COMPANION 3\* handsfree unit for complete handsfree or group telephone conversations can be easily added—now or later. The set can be used on your desk or it can be mounted on a wall, whichever is more convenient.

\*Trademark of  
Northern Electric Company Limited





# Operating

## Controls

The only controls on the LOGIC 10 set are the nine line buttons, the hold button and a headset/handset selector switch. (In some cases, optional features such as signalling can be added to this selector switch.)

Each line button lights when its associated line is in use. The light goes out when the line is idle. The line button flashes when an incoming call is ringing and winks when the line is placed on hold.

The hold button is red in colour. When pressed and released, it places the line in use on hold and releases the line button.

The headset/handset selector switch is used for headset operation with the LOGIC 10 set.

## Placing a call

To place a call, press an idle line button, lift the handset and listen for dial tone, and dial the desired number.

## Answering a call


When the telephone set rings, press the flashing line button and lift the handset.

## Holding a call

To place a call on hold, press and release the red hold button. The line button corresponding to the line on hold will wink to indicate that the line is being held. You may place or answer calls on any of the other lines while one or more calls are being held. To re-enter a held call, press the winking line button.

## Terminating a call

When a call has been completed, replace the handset in the two recesses in the front cover.



# Optional features

Your LOGIC 10 set may have other service features such as add-on, exclusion, intercom or signalling, provided these service features are available in your key telephone system.

## Add-On

The add-on feature enables you to add a third person to an outside call. To use add-on, press the hold button, press an idle line button, and dial the number of the third person. Depress the add-on button to add the third person before or after the call is answered as desired.

To release one of the parties, press the line button associated with the person you wish to retain and press the add-on button.

## Signalling

You can signal another person by pressing the signal button which operates a buzzer or light at another location.

## Exclusion


You can obtain privacy during a telephone conversation by pressing the exclusion button. The line is restored to normal service when the handset is replaced.

## Intercom

You can call other extensions in your key telephone system by pressing the intercom button and lifting the handset or by dialing the desired intercom number.

## Other optional services

Many other optional services are available. Consult your local telephone company.



The bottom handset recess provides a convenient and secure off-hook resting place for the handset.

## Alternate faceplate colours

The easily changed faceplates on LOGIC 10 sets are available in five colours: sand, dark brown, deep green, deep blue and purple.



## Using a headset with your LOGIC 10

You can enjoy the advantages of private, handsfree telephone conversations by using COMPANION 1\* or other headset with your LOGIC 10 key telephone set. All LOGIC 10 sets contain provision for activation of this feature by the installer.

### Answering a call

Turn the selector switch to the right.

### Terminating a call

Turn the selector switch back to the vertical position.

### Transferring from headset to handset operation during a call

Lift the handset and turn the selector switch back to the vertical position.



## Using the COMPANION 3 handsfree unit with your LOGIC 10

You can enjoy the convenience of complete handsfree telephone conversations and group telephone conversations by adding the COMPANION 3 handsfree unit to your LOGIC 10 set. This unit is installed simply by plugging it into any LOGIC 10 set which has been modified to accept it. All LOGIC 10 sets contain provision for activation of this feature by the installer.

### Placing a call

To place a call, press an idle line button on the LOGIC 10 set, press the "On" key momentarily on the COMPANION 3 unit and dial the number.

### Answering a call

To answer a call, press the flashing line button on the LOGIC 10 set, and the "On" key momentarily on the COMPANION 3 unit.

### Holding a call

To hold a call, press and release the hold button on the LOGIC 10 set.

### Terminating a call

When a call has been completed, press the "Off" key on the COMPANION 3 unit.

### Other features

Depressing and holding the "Mute" key on the COMPANION 3 enables you to hold a local conversation without it being transmitted to your party. Release of the key resumes transmission.

A small red light on the front of the unit flashes on and off as the direction of conversation changes.

A loudspeaker volume control enables you to adjust the level of the incoming conversation as desired.

