

CIVIL AIR RAID WARNING EQUIPMENT

B.S.P. Sections -----Information: A804.526
Routine Tests: A204.526


Equipment-----Line Connector SD-95678-01
Dial Pulse Rec. SD-95678-01
Code Generator SD-95677-01
Station Indicator SD-69211-01
Line and Equipment jacks SD-95683-01
Balanced Loop Repeater SD-95681-01
Fuse Alm & Pos. Bat. Cont. SD-81202-01

NOTE: Caution must be observed in making any tests or adjustments to prevent FALSE SIGNALS to subscribers.


1. Repeater Ckt. #1 is connected to Line and Equipment jks. #1.
- ~~2. Repeater Ckt. #2 is connected to Line and Equipment jks. #2.~~
- ~~3. In the event of trouble in Rep. Ckt. #1, the system may be trans. to Rep. Ckt. #2 by patching (L) Jk-1 to (Eq-1) Jk.-2 and (LP) Jk. -1 to (Eq-2) Jk-2.~~
4. Rep. Ckts #1 and ~~#2~~ are equipped with open ckt. alarms. If the ckt. goes open a major alarm results. To retire the alarm, operate the ACC key on the Repeater. A green guard (G) lamp will stand in as long as the open ckt. exists.

SC-824 STATE OFFICE OF CIVILIAN DEFENSE
REGION 3

REFER CIRCUIT ORDER 6000 & IXPL C-9433



OAKLAND IS CONTROL OFFICE



SC-824 State Office Of Civilian Defense

Region 3

San Francisco Metropolitan Area

Refer C.O. 7032 and IXPL P-2099 3-27-53

