

TO MISC. ALM. CKT. (SELECTORS)
TO SW. TROUBLE ALM. CKT.,
TO SUPERVISORY CKT. (A & M ONLY),
TO ALM. CKT. FOR SEL. FR.S. (A & M ONLY)
OR TO MISC. TONE AND TONE ALM. CKT.

TO SUPERVISORY CKT. (A & M ONLY),
TO ALM. CKT. FOR SEL. FR.S. (A & M ONLY)
OR TO SW. TROUBLE ALM. CKT.
OR TO MISC. ALM. CKT. (SELECTORS)

TO RECEIVER OFF HOOK
TONE CONNECTING CKT

FIG. 1
SELECTOR CKT

FIG. 2 (MFR. DISC.)
BANK MULT

FIG. 3	APP. OR WIRING
1	Z
2	Y
	X
	W
	V
	U
	T
	S
	R
	Q
	P
	O
	N
	M
	L
	K
	J
	I
	H
	G
	F
	E
	D
	C
	B
	A


TO COMMON
NUMBER AND
CLASS CKT.

NO. 20 AWG

TO SEL BANK MULT
CKT., TO LINE SW
BANKS, LINE FINDER
OR SELECTOR MULT,
REPEATER, OR TRK
CKT. AS REQ. OR TO
CONVERTER TRUNK
AND LINK

TO RECEIVER
OFF HOOK
TONE
CONNECTING
CKT


TO LINE
FINDER



SD-30200-01 SELECTOR

S.P.C.

TO FIG 2 OR
THRU SEL BANK TO FIG. 1
MULT. CKT. TO SEL.,
CONN. REP. OR
TRK. CKT.



C (V,F)
NETWORK
SEE NOTE
106