



502-510-450CA  
U.S. Bell System  
502-510-450

N.B. - FOR GROUND RINGING  
MOVE BLACK LEAD FROM  
RINGER FROM TERMINAL  
"L1" TO TERMINAL "G".

NOTE : N.E. & W.E. 25A3 ( 10 BUTTON ) & 35A3 ( 12 BUTTON )  
TOUCH TONE DIAL PADS HAVE 7 LEADS EACH, AND  
ARE COLORED CODED AS FOLLOWS ..... GREEN /  
RED / BLACK / WHITE / BLUE / ORANGE-BLACK AND  
RED-GREEN. THEY ARE MARKED ON THE DRAWING  
WITH THE COLOR PLUS THE WORD "DIAL".

© JEFF LAMB

N.E. & W.E. TELEPHONE SETS 1500D, 2500D, 1554B, 2554B CONNECTED TO 25A3 & 35A3 TOUCH TONE DIAL PADS