


501 A



WHEN USED WITH DESK STANDS, FLEXIPHONES OR TRANSMITTER ARMS EQUIPPED WITH AN INSULATED TRANSMITTER AND THREE CONDUCTOR EXTENSION CORD,

CONNECT "L1" TO LINE 1.

CONNECT "L2" TO LINE 2.

CONNECT "B1" TO ONE TERMINAL OF BATTERY.

CONNECT "B2" TO OTHER TERMINAL OF BATTERY.

CONNECT CONDUCTOR OF EXTENSION CORD HAVING YELLOW TRACER TO "Y."

CONNECT CONDUCTOR OF EXTENSION CORD HAVING RED TRACER TO "R."

CONNECT CONDUCTOR OF EXTENSION CORD HAVING GREEN TRACER TO "GN."

PATENTED IN U.S.A.
FEB. 26, 1924