



**Circuit Diagram for Connections with Prepay Manual and Rotary Dial Coin Collectors**

**TABLE A**

**CONNECTIONS FOR PREPAY MANUAL AND ROTARY-DIAL COIN COLLECTORS**

| TYPE OF SERVICE  |  | TERM.<br>LOC.  | SUBSCRIBER SET CONNECTIONS (WIRE OR LEAD) |    |    |     |                                       |                  |      |                                   |    |    |    |    |    |  |
|--|--|----------------|---|----|----|-----|---------------------------------------|------------------|------|-----------------------------------|----|----|----|----|----|--|
| PREPAY MANUAL AND<br>ROTARY — DIAL TYPE<br>COIN COLLECTORS |  |                | RINGER LEAD<br>(Note 1)                   |    |    |     | STRAPS — NETWORK<br>TO TERMINAL STRIP |                  |      | LOCAL WIRE FROM<br>COIN COLLECTOR |    |    |    |    |    |  |
| CURRENT CODES  | MD CODES   |                | S   | BK | R  | S-R | [S-BR] (BR)                           | BL               | BR-Y | R                                 | G  | BK | Y  | G  | R  |  |
| 191, 195, 196, 197<br>(CNT, DNT, GNT,<br>HNT)              | 191, 195, 196, 197<br>(CN, DN, GN, HN,<br>CNS, DNS, GNS,<br>HNS) | Ntwk.          | K   | —  | —  | —   | See<br>Note<br>2                      | See<br>Note<br>3 | A    | R                                 | GN | B  | RR | —  | —  |  |
| 220, 223<br>(CT, DT, GT, HT)                               | 220, 223<br>(C, D, G, H)   | Term.<br>Strip | —   | L1 | L2 | 1   |                                       |                  | 1    | —                                 | —  | —  | —  | L2 | L1 |  |
| 230G   | 230, 233<br>(C, D, H)  |                |   |    |    |     |                                       |                  |      |                                   |    |    |    |    |    |  |
| 233G   |  |                |   |    |    |     |                                       |                  |      |                                   |    |    |    |    |    |  |
| 234G   |  |                |   |    |    |     |                                       |                  |      |                                   |    |    |    |    |    |  |

Notes: 1. All connections are shown for bridged ringing, individual line installations. If other ringing arrangements are required, refer to section on connections for 685 subscriber sets used with hand telephone sets.

2. Disconnect the [S-BR] (BR) wire from 2 on terminal strip and connect it to L2. The other end of this wire is connected to C of the network.

3. Disconnect and remove the BL strap wire between RR of network and L1 of terminal strip.