



Circuit Diagram for Connections with Prepay TOUCH-TONE Dial Coin Collectors

TABLE B

CONNECTIONS FOR PREPAY TOUCH-TONE DIAL COIN COLLECTORS

| TYPE OF SERVICE | TERM. LOC. | SUBSCRIBER SET CONNECTIONS (WIRE OR LEAD) | | | | | | | | | | | | | |
|-----------------|-------------|---|----|----|-----|------------------------------------|------------|------|--------------------------------|----|----|----|----|----|---|
| | | RINGER LEAD (Note 1) | | | | STRAPS — NETWORK TO TERMINAL STRIP | | | LOCAL WIRE FROM COIN COLLECTOR | | | | | | |
| | | S | BK | R | S-R | [S-BR] (BR) | BL | BR-Y | R | G | BK | Y | G | R | Y |
| 1234G | Ntwk. | K | — | — | — | See Note 2 | See Note 3 | A | R | GN | B | RR | — | — | C |
| | Term. Strip | — | L1 | L2 | 1 | | | 1 | — | — | — | — | L2 | L1 | — |

- Notes: 1. All connections are shown for bridged ringing, individual line installations. If other ringing arrangements are required, refer to section on connections for 685 subscriber sets used with hand telephone sets.
2. Disconnect and remove the [S-BR] (BR) strap wire between C of network and 2 of terminal strip.
3. Disconnect and remove the BL strap wire between RR of network and L1 of terminal strip.
4. Early models of the 1234G coin collector used a 685D subscriber set which is rated MD.