

## NOTES:

- DOTTED LINES SHOW SETS WITH MANUAL CONNECTIONS [230, 233 (C AND D)] DIAL IS REPLACED WITH 50C APPARATUS BLANK.
- 2. WHEN A GIR FILTER IS REQUIRED FOR RADIO FREQUENCY SUPPRESSION, MOVE (Y) DIAL LEAD FROM Y UPPER HOUSING CONTACT SPRING TO FILTER BRACKET TERM., CONNECT (Y) FILTER LEAD TO FILTER BRACKET TERM., CONNECT (BK) FILTER LEAD TO BK UPPER HOUSING CONTACT, AND CONNECT (R) FILTER LEAD TO Y UPPER HOUSING CONTACT.

DP - DIAL PULSE CONTACTS

HT - HOPPER TRIGGER CONTACTS

SH - SWITCHHOOK CONTACTS

ON - OFF NORMAL CONTACTS

TC - TRANSFER CONTACTS

DS - DIAL SHORTING CONTACTS

230, 233 (C, D, G, H) and 234G Coin Collectors with 685A Subscriber Set—Coin First, Connections