



NOTES:

1. DOTTED LINES SHOW SETS WITH MANUAL CONNECTIONS
[230, 233 (C AND D)] DIAL IS REPLACED
WITH 50C APPARATUS BLANK.
2. WHEN A 6IR FILTER IS REQUIRED FOR RADIO FREQUENCY
SUPPRESSION, MOVE (Y) DIAL LEAD FROM Y UPPER HOUSING
CONTACT SPRING TO FILTER BRACKET TERM., CONNECT (Y)
FILTER LEAD TO FILTER BRACKET TERM., CONNECT (BK)
FILTER LEAD TO BK UPPER HOUSING CONTACT, AND
CONNECT (R) FILTER LEAD TO Y UPPER HOUSING CONTACT.
3. REMOVE THE (Y) STRAP BETWEEN TERMINALS 3 AND T
WHEN USED WITH THE 685B SUBSCRIBER SET.

- DP - DIAL PULSE CONTACTS
HT - HOPPER TRIGGER CONTACTS
SH - SWITCHHOOK CONTACTS
ON - OFF NORMAL CONTACTS
TC - TRANSFER CONTACTS
DS - DIAL SHORTING CONTACTS

230, 233 (C, D, G, H) and 234G Coin Collectors with 685B Subscriber Set—Coin First, Connections