



Western Electric

INSTRUCTIONS FOR USING 2012A AND 2012C
TRANSFORMERS WITH 701, 702, AND 2702
PRINCESS TELEPHONES*

(ALSO APPLICABLE TO ROUND BUTTON TRIMLINES &
ROTARY TRIMLINES WITH NON-LED LIGHT FEATURE)




Trimline sets that use the non-LED lit dial and light transformer do not have a night light selector switch



SETS, USE A 4-WIRE LINE CORD PLUGGED INTO THE SIDE MARKED "PHONE".

The following pictures show the typical hookup for a Princess or Trimline using a dial light transformer.

DIAGRAM OF PRINCESS/TRIMLINE
DIAL LIGHT WIRING HOOKUP



This picture shows how the dial light transformer as it would be connected in a typical installation. This diagram assumes you have the modular equipped transformer & 338A adapter already, or the direct-wired dial light transformer.

FOR ROUND BUTTON TRIMLINES YOU SHOULD USE THE OLDER 2012 "A" AND "C" TRANSFORMER.



CAUTION: IT IS NOT RECOMMENDED to use the AT&T (QLT Lease Corp.) transformer and adapter with a older round button Trimline, it can melt the flex circuit in the handset, rendering it inoperative.

TO USE THE NEWER AT&T (QLT Lease Corp.) TRANSFORMER WITH THE OLDER PRINCESS

**DIAL LIGHT TRANSFORMER INSTALLATION
STEPS FROM DIAGRAM:**

1. PLUG LINE CORD INTO PRINCESS OR TRIMLINE LINE CORD JACK.
2. PLUG LINE CORD FROM PRINCESS INTO **338A ADAPTER**. THEN PLUG 338A ADAPTER INTO PHONE JACK.
3. CONNECT CORD TO **338A ADAPTER** TO GO TO **DIAL LIGHT TRANSFORMER** PLUG IT INTO THE **DIAL LIGHT TRANSFORMER**.
4. CONNECT DIAL LIGHT TRANSFORMER TO A 110 VOLT AC OUTLET.

THE CORDS FROM THE PHONE AND TRANSFORMER MAY BE CONNECTED TO EITHER SIDE OF THE 338A ADAPTER.

FOR AT&T (QLT Lease Corp.) DIAL LIGHT TRANSFORMERS USING THE ADAPTER SUPPLIED, PLUG PHONE'S CORD INTO SIDE OF ADAPTER MARKED "PHONE", AND DIAL LIGHT TRANSFORMER'S CORD INTO SIDE MARKED "POWER".

PLUG ADAPTER INTO PHONE JACK, AND TRANSFORMER INTO 110 VAC OUTLET.