TABLE D

2702BM AND 2702BMG TELEPHONE SET LINE AND RINGER CONNECTIONS WITH D4BU MOUNTING CORD

					TIP PARTY		
			INDIVIDUAL OR BRIDGED (NOTE 3)	RING , PARTY	NO IDENT GRD.	IDENTIFYING GROUND (NOTE 4)	
WIRE OR L	WIRE OR LEAD					1000 OHMS	2650 OHMS
Line Wire	Ring	R	R	R	R	R	R
at	Tip	G	G	G	G	G	G
Conn Block	GRD	Y	Y	Y	Y	Y	Y
Dial Light	1	Y	Y	Y	Y	Y	Y
Transformer	2	BK	В	В	В	В	В
	623P4 Jack Assembly in Set (Note 2)		L2	L2	L1	С	С
			L1	L1	L2	L2	L2
Set			3	3	3	3	3
(Note 2			4	4	4	4	4
			L1	3	3	3	3
Ringer Lead (Note 1)		R	К	К	K	К	K
		S	*	*	*	L1	*
			*	*	*	*	L1
	Line Switch at Net. (Note 5)		F	F	С	В	В
			C	C	F	F	F
Strap of N	Strap of Net.		A	A	A	*	*

Note 1: To silence ringer permanently for all classes of service, refer to the appropriate section in Division 501.

Note 2: When connecting the 623P4 jack assembly leads for tip party identifying ground, use D-161488 connectors and M1W straps as required to extend conductor leads.

Note 3: Sets are factory-wired for bridged service.

Note 4: For tip party service with identifying ground, remove insulate and store (BK) strap between network terminals A and H.

Note 5: This change does not apply to sets equipped with a polarity guard.

^{*} Insulated and stored.