



Circuit Diagram for Connections with Postpay Manual and Rotary Dial Coin Collectors

TABLE C

CONNECTIONS FOR POSTPAY MANUAL AND ROTARY-DIAL COIN COLLECTORS

TYPE OF SERVICE		TERM. LOC.	SUBSCRIBER SET CONNECTIONS (WIRE OR LEAD)																
POSTPAY MANUAL AND ROTARY-DIAL TYPE COIN COLLECTORS			INSIDE WIRE FROM LINE OR PROTECTOR			RINGER LEAD (Note 1)				STRAPS — NETWORK TO TERM. STRIP		LOCAL WIRE FROM COIN COLLECTOR							
CURRENT CODES	MD CODES		R	G	Y	S	BK	R	S-R	[S-BR] (BR)	BL	BR-Y	R	G	BK	Y	G	R	
200C	182CN, DN 193GN, HN 198GN, HN	Ntwk.	—	—	—	K	—	—	—	See Note 2	See Note 3	A	R	GN	B	—	—	RR	
210G	200D	Term. Strip	L1	L2	—	—	L1	L2	1			1	—	—	—	L1	—	—	
212G	210H 212H																		

- Notes: 1. All connections are shown for bridged ringing, individual line installations. If other ringing arrangements are required, refer to section on connections for 685 subscriber sets used with hand telephone sets.
2. Disconnect the [S-BR] (BR) wire from 2 on terminal strip and connect it to L2. The other end of this wire is connected to C of the network.
3. Disconnect and remove the BL strap wire between RR of network and L1 of terminal strip.