WIRING DIAGRAM FOR 1270 TELEPHONE.



NOTES.

1. TO CONVERT FROM MANUAL TO DIAL TYPE, REMOVE STRAP "B" AND WIRE DIAL CABLE AS SHOWN BY DOTTED LINES. IF A DIAL WITHOUT CABLE IS USED, ORDER ONE 35861 CABLE FROM STROMBERG CARLSON CO.
2. ON SHORT TRUNKS TO EXCHANGE (ABOUT 200 Ω D.C. LOOP RESISTANCE OR LESS) FOR REDUCED SIDETONE, CONNECT STRAP "D" BETWEEN 8 AND 9, "F" BETWEEN 10 AND 14, AND G BETWEEN 5 AND 4. ALSO, CONNECT RED OF HOOKSWITCH AND GREEN OF DIAL (IF USED) TO 9.