HAND TELEPHONE SETS — 211E, F, G, H

LOCAL BATTERY — CONNECTIONS

1.00 INTRODUCTION

This section covers the combination of apparatus, circuit diagrams, and connections for the 211-type hand telephone sets for local battery talking—common battery signaling service.



FIG. 1-211 TYPE MANUAL



FIG. 2-211 TYPE DIAL

TABLE A-COMBINATION OF APPARATUS

Hand	Components					
Tel. Set Code	Handset	Handset Cord	Handset Mounting	Dial or Apparatus Blank	Dial Mounting	Note
211E-3E	E1E-3			_		1, 2, 4
211E-3F	F1A-3, F1G-3, or F4A-3					
211F-3E	E1E-3	-				
211F-3F	F1A-3, F1G-3, or F4A-3			4HA-3 or 5HA-3	41A-3 or 43A-3	1, 2, 3, 4
211G-3E	E1E-3	H 3	G1-3	4HB-3, 5HB-3 or 6A		
211G-3F	F1A-3, F1G-3, or F4A-3					
211H-3E	E1E-3			4HC-3 or 5HC-3		
211H-3F	F1A-3, F1G-3, or F4A-3					

Notes

- 1. Codes listed are for apparatus with black finish. For apparatus finished in other colors, the dash number (-3) is changed to the code number for the particular color.
- 2. The letter in the hand telephone set code number denotes whether set is manual or dial, and type of dial number plate when dial.
- 3. May be equipped with 61M filter.
- 4. When the handset is equipped with spring cord, the suffix R will be added to the set code. For example, a 211G-3F become a 211GR-3F.




FIG. 3-F1G-3 HANDSET




Fig. 4—6A Dial

ASSOCIATED APPARATUS


	Class of Service	Sub. Set
TABLE B	Individual Lines PBX Stations 2-Party Flat Rate 2-Party Message Rate (Manual and Ring Party Dial) 4-Party Semiselective Multiparty Divided Code Multiparty Nonselective	634Y, YD
	4-Party Selective	634YT, YDT
	8-Party Semiselective	
	Class of Service	Sub. Set
TABLE C	Individual Lines PBX Stations 2-Party Flat Rate 2-Party Message Rate (Manual and Ring Party Dial) 4-Party Semiselective Multiparty Divided Code Multiparty Nonselective	Sub. Set 634Y, 634YD (Rewired)

2.00 GENERAL

2.01 The 634YD or YDT subscriber set should be used if hand telephone set is equipped with F-type handset.



- 2.02 Hand telephone sets equipped with E-type handsets may be used with any of the above subscriber sets providing their use does not conflict with transmission zoning requirements.
- 2.03 When hand telephone sets equipped with E-type handsets are used with the 634Y or YT subscriber sets, the 557B or 574A receivers shall be tested and connected for proper polarity as follows:
 - After all connections have been made, remove the receiver cap and check
 the magnetic pull on the diaphragm. Reverse the line-wire connections
 on L1 and L2 of the subscriber set and recheck the magnetic pull. Restore connection of line wires to normal.
 - The magnetic pull on the diaphragm should be greatest with the line wires normal. If not, make the following changes in the subscriber set:
 - a. Remove BK lead from L1 and connect to L2GN.
 - b. Remove GN cord lead from L2GN and connect to L1.



- 3.01 When filters are required for radio-frequency suppression, equip the hand telephone sets with 51M filters, connected as shown in Fig. 6. Removal of the M1W cord between the Y terminal of dial and the W terminal of switchhook is required when filter s provided.
- 3.02 Where transmitter battery for more than one station is obtained from a common source, nodification of hand telephone sets is required. This nodification consists of replacing regular handset with a E2B, E2C, or F2B handset connected as shown above.




Fig. 6—61M FILTER CONNECTIONS